



Software Version

No.	Version	Date	Note
1	V1.0	2024-07-25	Original release.





Controller models to which this manual applies:

EC40CR



Symbol Description

Symbol	Description	
Note	Remind operators to operate correctly, otherwise it may cause the equipment not to work correctly.	
	It is indicated that potential hazards can damage equipment without proper precautions.	
Warning	It is indicated if appropriate preventive measures are not taken, potentially dangerous situations may result in death, serious personal injury or significant property losses.	





- 1. The installation of this equipment must be carried out by professionals.
- 2. When installing and operating the controller, please read the entire instruction manual first.
- 3. Any maintenance and commissioning of the equipment must be familiar with all the equipment.
- 4.Safety standards and precautions in advance, otherwise it may cause personal injury or damage to related equipment.
- 5. After the installation of the controller is completed, please verify that all protection functions are valid.



- 1.Please keep the good connection of the power supply of the controller. Do not share the connection lines of the positive and negative electrodes of the battery with the floating charger.
- 2.During the operation of the engine, do not disconnect the battery, otherwise it may cause damage to the controller.



Catalogue

Summary	7
Main Features	7
Parameters Display	8
Protection	8
Parameters	8
Overall Dimension and Wiring Diagram	9
Installation instruction	15
Panel and display	
Key Function Description	16
Commissioning and precautions	23
Warnings and Shutdown Alarms	24
Parameter setting	
Fault finding	44

Notes:

1. All rights reserved. No part of this duplication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or others) without the written permission of the copyright holder.

2. MEBAY Technology reserves the rights to change the contents of this document without prior notice.

MCBV

Summary

This series of controllers are mainly used in engine control systems for water pumps, lighthouses, air compressors and engineering machinery types, applicable to stand-alone automatic control monitoring system, with remote start and stop, data measurement, alarm protection functions.

2.8 inch LCD screen display with brand new UI design is adapted in this controller can display related parameters directly. The LCD screen can display various faults at the same time. Once the unit does not run normally, it can effectively achieve protection.

There are Chinese/English interface options, more language can be set according to user's request. All the parameters can be configured through the front face buttons or use programmable interface by RS485 or USB to adjust via PC.

Main Features

- ◆ 32bit high performance single chip microcomputer.
- ♦ 2.8 inch LCD screen, It has 16 display languages including Chinese and English, user's language set if necessary.
- ◆ Indicator and number display through UI surface.
- Acrylic material is adapted to protect the screen.
- Silicone panels, waterproof, oil-proof, UV-resistant, good operation feel and long service life.
- USB Port: parameters can be set even without power through USD port to monitor in real time.
- With RS485 communication port, can achieve "Three Remote" functions via MODBUS protocol.
- Standard CAN communication port, built-in J1939 protocol.
- ◆ Various kinds of parameters display.
- Input/output function, status can be shown directly.
- ◆ More categories of surface setting.
- ♦ Real time clock inside: preset time operate and auto maintenance is available. Engine working plan can be set as per week or month.
- ◆ Protection countdown function, which can set the maintenance time or date.
- Equipped with black box function: capable of storing 100 sets of alarm records, including relevant parameters of the unit when a fault alarm occurs, facilitating the search for the cause of the fault;
- ◆ Equipped with event recording function: can save 5000 system operation logs;
- Equipped with operation record storage function: can save 5000 engine operation records for easy understanding of engine operation status;
- ◆ Totally 7 relay's output, among which 5 relay output can be self-configurable, each relay can be set as max 80 functions.
- With 6 switches input, up to 50 functions optional.
- ♦ 6 sensor simulation input connectors, 3 input types is configurable and various kinds of units can be set.
- Battery charging control function, which can protect the battery according to battery voltage status.
- ♦ Sensor can be self-defined by front face button or PC software.
- ♦ Various of crank conditions (RPM, External input , Oil Pressure,) can be chosen.
- ♦ Control Protection: Auto Start/Stop of unit, perfect failure display and protection.
- ♦ Standard water-proof rubber gasket. The waterproof can reach IP65.
- Module design: All the connections are adapted with European connectors so that installation, connection, repair and replacement can be more easily.

Parameters Display

- Engine RPM
- Engine oil pressure
- Engine water temperature
- ♦ AUX.sensor parameters
- Engine battery voltage
- Charging voltage
- Cumulative power-on time
- Total Crank times
- Current running time
- Total running time
- Maintenance notice
- 6 switches input status display
- Output status display of 7 relays

Protection

- Over speed
- Under speed
- RPM Lost
- Low oil pressure
- High Engine water temperature
- Low fuel level
- Crank failure
- Stop Failure
- Emergency pull over
- Sensor Open
- ECU alarm failure
- ECU communication Failure
- Low water level alarm
- Failed to charge
- Over battery voltage
- Under battery voltage
- External real-time alarm
- Maintenance expire
- All warnings
- Alarm shutdown

Parameters

Options	Parameters
Working voltage	DC 8V36V Continuous
Power consumption	Working: 24V MAX 1W (Standby:24V MAX 5W)
Rotate speed sensor Frequency	50-10000 Hz(AC1~70V)
MAX Accumulating Time	99999.9Hours (Min Store time:0.01H)
Crank Start Relay Output	Max 5Amp/250VAC Non-contact normally Open output
AUX. OUTPUT 1-5	Max 5Amp/250VAC Non-contact normally Open output
AUX. OUTPUT 6	Max 3AMP/250V Non-contact normally Open&Closed output
Sensor INPUT	6 configurable sensor inputs
Excitation output	DC+VE supply voltage



AUX.INPUT 1-6	Available if connecting with Battery -
Working condition	-25-70 ℃
Storage condition	-30-80 ℃
Protection Level	IP65: when waterproof rubber gasket is added between controller and its panel
Insulation strength	Apply AC 2.2kV voltage between high voltage terminal and low voltage terminal; The leakage current is not more than 3mA within 1min.
Overall dimension	142mm*105mm*45mm
Panel cutout	116mm*90mm
Weight	0.5Kg

888



114.5-





No.	Function	Description Cable of sectiona	ross I area
1	Battery Negative Input B-	Controller power supply input B	1.5mm ²
2	Battery Negative Input B+	Controller power supply input B+.	1.5mm ²
3	COM 1 Relay Common Port	Relay output common port of No.4 and No.5.	1.5mm ²
4	Crank Output	Non-contact normally opened output, Max 5Amp.	1.5mm ²
5	Aux. Output 1	Non-contact normally opened output, Max 5Amp.	1.5mm ²
6	COM 2 Relay Common Port	Relay output common port of No.7, No.8 and No.9.	1.5mm ²
7	Aux. Output 2	Active output, Max 5Amp/250V.	1.0mm ²
8	Aux. Output 3	Active output, Max 5Amp/250V.	1.0mm ²



9	Aux. Output 4		Active output, Max 5Amp/250V.	1.0mm ²
10	Aux.	Normally Open	Non-contact normally opened output, Max	1.0mm ²
11	Output 5	СОМ	5Amp/250V.	1.0mm ²
12		Normally Open		1.0mm ²
13	Aux.	Normally Close	Non-contact normally opened/closed output, Max 3Amp/250V	1.0mm ²
14	oupuro	СОМ		1.0mm ²
15	CAN_H		ECU communication interface : 120Ω	0.5mm ²
16	CAN_L		with one end arounded.	0.5mm ²
17	RS485 A		RS485 communication interface : 120Ω	0.5mm ²
18	RS485 B		impedance shielding wire is recommended with one end grounded.	0.5mm ²
19	Aux. Input	1	<u> </u>	1.0mm ²
20	Aux. Input	2		1.0mm ²
21	Aux. Input	3	The grounding is valid according to the	1.0mm ²
22	Aux. Input	4	function selection switch input.	1.0mm ²
23	Aux. Input	5		1.0mm ²
24	4 Aux. Input 6			1.0mm ²
25	Charger D+ output		Active output, Connected with D+(W/L) terminal of charger.	1.0mm ²
26	Aux. Input	СОМ	Internally connected to B-	1.0mm ²
27	Charger W	/L	Connect with W terminal of charging engine.	1.0mm ²
28	Speed sen (connect w	sor MP2 ith B-)	Use a shielded wire to connect the speed	1.0mm ²
29	Speed sensor MP1		sensor.	1.0mm ²
30	AUX.Senso temperatur	or 1-Engine e sensor	Sensor inputs are configurable. (only resistive type can be configured)	1.0mm ²
31	AUX.Sensor 2_Oil pressure		Sensor compatible with voltage ,current and resistance.	1.0mm ²
32	AUX.Sense	or 3	Sensor inputs are configurable. (only resistive type can be configured)	1.0mm ²
33	AUX.Sense	or 4	Sensor inputs are configurable. (only resistive type can be configured)	1.0mm ²
34	AUX.Sensor 5		Sensor compatible with voltage ,current and resistance.	1.0mm ²
35	AUX.Sense	or 6	Sensor compatible with voltage ,current and resistance.	1.0mm ²
36	+5V Outpu	t	Connect the power supply of the oil pressure sensor with the output voltage signal, with a maximum of 50mA.	1.0mm ²
37	Sensor cor	mmon GND	Connect the battery negative or outer.	1.0mm ²



EC40CR Typical Wiring Diagram



NOTE: The Charger negative needs to be separately connected to the case or the negative terminal of the battery.

NOTE: To ensure reliable operation of the module and the measuring accuracy, Try not to share the power cord with other devices.

◆ D-Driven pump start/stop operation and wiring diagram.

- 1) Set input function: D-driven pump started, press. to suction pump.
- 2) Set output function: D-driven pump start, D-driven pump stop.
- 3) Suction pump type: D-driven.
- 4) D-driven pump start:

① After auto/manual mode start is active, preheat relay outputs (if configured), and LCD displays "Preheat delay XX". After preheat delay finished, starting relay outputs (needs to be configured). If crank success input (needs to be configured) is invalid during "D-driven pump cranking Time", starting relay stops output and it will go

MCBAY EC400

to "suction pump crank rest" then waiting for next crank. If the pump doesn't crank successfully in setting cranking times, controller will issue crank failure shutdown and in the meanwhile it will show "suction pump crank failure" in LCD display.

② In any time of cranking, if D-driven pump crank success, it will enter to "waiting press.to" delay. When delay is expired, "press. to suction pump" (needs to be configured) is invalid and controller will raise alarm and shutdown, and meanwhile "suction pump fault" will be displayed on LCD.

③ During the time of "waiting pressure to", fuel relay output set "prestart fuel time" (default 1s) after "press. to suction pump" (needs to be configured) is valid, and then starting relay outputs. The rest starting processes are same with auto start procedure.

5) D-driven pump stop: After "safety on delay", "D-driven pump stop" outputs (needs to be configured), and it stops to output after "Energize to stop time".



◆ E-Driven pump start/stop operation and wiring diagram.

1) Set input function: Press. to Suction Pump.

2) Set output function: E-driven Pump Start.

3) Suction pump type: E-driven.

4) driven Pump Start: After suction pump type is set as E-driven pump and "Safety On Delay" is over, the starting relay outputs (needs to be configured).

5) driven Pump Stop:

① While engine is between start idle and high-speed cooling time, if input is "Press. to Suction Pump" (needs to be configured) or outlet pressure is larger than the value of E-driven stop outlet pressure value, the starting relay stops output.

While engine is in "Energize to Stop Delay", the starting relay stops output.

NOTE: The mentioned outlet pressure of E-driven pump needs to be set in outlet pressure correlation setting, then relate to corresponding programmable sensor.





Installation instruction

- The controller is fixed by two special fixing members and screws, and the screws of the metal fasteners cannot be too tight.
- ◆ Panel Cutout: W116mm*H90mm.

Т	116.00 mm
00.00 mm	
	<u> </u>

Note: If the controller is installed directly in the engine shell or other fluctuated equipment, the rubber pad must be installed.

◆Battery Voltage Input

EC40CR controller is suitable for 8-36V DC battery voltage. Battery negative must be reliably connected to the enclosure of the engine. The controller power supply B+ and B- must be connected to battery positive and negative, and the wire size must not be less than 1.5mm².

In case of floating charger connect charger output to battery positive and negative directly, then, connect battery positive and negative poles to controller positive and negative power supply.

Output and relay expansion

Note: All outputs of the controller are relay contacts. The maximum current capacity is described in the "Parameters" in this manual. Please use it in the relay current capacity. If an extended relay is needed, add a continuous current diode (when the extended relay coil is DC) or a resistance-capacitance loop (when the extended relay coil is AC) to both ends of the coil to prevent interference with the controller or other equipment.

If withstanding voltage test is conducted after the controller has already been installed onto the control panel, please unplug all controller terminal connections in order to prevent high voltage from damaging it.



Panel and display

MCBAY			
Alarm - Warning - Running -	ALARM WARN WARN RUN	10 15 10 10 10 10 10 15 10 10 10 10 1500 10 10 10 10 1500 10 10 10 10 1500 10 10 10 10 1500 10 10 10 10 1500 10 10 10 10 1500 10 10 10 10 1500 10 10 10 10	
Stop status	STOP		
	Auto stat	us Speed status Manual status Start status	
Key Function	n Description	Main Eurotion	
	Stop Revert	 In manual/automatic mode, stop the engine when pressed.; In stopping process, press this key again to stop the engine quickly. In setup mode, cancel the modification and return to the upper menu; In setting mode parameter browsing mode, press it to exit the setting interface and save the data. In the standby state of stopping gear and without any alarm, press this key for 3 seconds to view the alarm record. In the alarm state, you can reset any alarm shutdown. 	
	Start	 In manual mode, press this key to start the engine; the In stop gear, pressing this key oil valve and ECU power will output. (Valid when engine type is configured for CAN protocol). If the idle delay is pressed after a successful unit start, the idle run time is skipped. 	
	Auto	◆ Pressing this key will set the module into auto mode.	
	Manual	◆ Pressing this key will set the module into manual mode.	
	Speed	♦ If the configuration speed control function is on, press this key to enter the speed control interface.	
	Up	 In setup mode, it will be possible to flip up to move the cursor or increase the number where the cursor is; In the history fault screen, press and move the cursor 	



		upwards; ◆ In the display mode, turn the page forward. ◆ In the speed control interface, it will be possible to increase the speed.
	Down	 In setup mode, it will be possible to move the cursor down or decrease the number where the cursor is; In the history fault screen, press and move the cursor downwards; In the display mode, turn the page backward. In the speed control interface it will be possible to reduce the speed;.
ОК	OK UI Change	 Confirm the change under edition mode. Shift right under edition mode. Page exited under records checking mode. In display mode, press to return to the display home page; In standby state, press for 3 seconds to enter the parameter setting mode.
	LED Test	◆ Test if all LED lights are OK, pressing this key to test if all lighted, all off when loosen it.
	Setting mode	 Pressing OK and STOP simultaneously to come into setting mode

♦ Alarm records checking

EC40CR controller can save 100 group of alarm records which contains the alarm record data includes detailed data such as alarm time,prompt status information, etc. How to check the alarm records:

1. Enter alarm record page: Under stop mode, press this **U**key for 3 seconds come into alarm records page; Enter the setting mode: Select the alarm record and

press key to alarm records page;

2. Press 🛆 to turn upper digit and press 💙 to turn lower digit in order to choose

the record you need. Press or to confirm the record and come into history records checking page.

3. Press \checkmark to turn lower records under records checking page. Press \bigtriangleup to turn

upper records and press U to revert back to alarm history records page.

4. Exit from records page: In the history records page and checking page, press

System Operational Records

EC40CR controller can save 5000 system operation records, including poweron time, date, cumulative time, starting mode (manual, automatic, unknown,), running time, stopping mode (manual, automatic, alarm stop, unknown), and writing running time and mode at intervals.

The steps to view the system log are as follows:

ΜΕΒΛΥ

1) Press the key 🥙 for more than 3 seconds.Or press the stop key 🛄 without

releasing, press the OK key again, and then release all the keys to enter the setting menu page;

2) In the setting menu page, select "System Operational Records" and press the

OK key once to enter the System Operational Records page;

3)In the System Operational Record page, press the up key 🛆 and down key

to browse the operation log, and the latest operation is recorded in the front;

press the STOP key U to exit the System Operational Records page.

◆ Maintenance expiry reset password

The controllers are equipped with a quick reset maintenance countdown function, which is operated as follows:

1) Press the key or for more than 3 seconds to enter the setting menu interface.

2) In the setting menu interface, press key to move down, select "Maintenance Countdown Reset", and input "Maintenance Countdown Reset Password".
3) In the pop-up dialogue box, select "Yes", the controller will reset the maintenance countdown to the set value.

4) After the maintenance countdown is reset successfully, the controller will exit the setting interface automatically.

Note: The maintenance countdown password cannot be set as the same as the parameter setting password!

♦ Idle mode:

1) Input port is configured as : Idle Mode.

2) If engine is normally running and idle mode input is active, controller will enter into idle mode and engine will start idle running. Then idle control relay will be energized and drop speed relay will output.

3) If engine is in standby status and idle mode input is active, engine will be started in manual mode or auto mode. When "Safety On Delay" is over, engine will enter into "Start Idle Delay" (if configured), and after this delay expired, engine will start idle running. Then idle control relay energized and drop speed relay will output.

4) While in idle mode and engine is idle running, if idle mode input is inactive, controller will exit idle mode, and engine will enter into normal running. Both Idle control relay and drop speed relay stop outputing.

5) While in idle mode and engine is idle running, press to **u**active stop operation, and then engine enters from "Idle Running" to "Stop Idle Delay". The remaining stop process is the same as auto stop procedure.

◆ Idle/High speed mode:

1) Input port is configured as : Idle/High speed.

2) If engine is normally running and idle/high speed input is active, engine will start idle running. Then idle control relay will be energized and drop speed relay will output.

If speed regualtion is configured as relay adjust speed or CAN adjust speed, press raise speed key, idle control relay and drop seed relay will stop output, and speed can be adjusted during idle running.

3) If engine is in standby status and idle/high speed input is active, engine will be started in manual mode or auto mode. When "Safety On Delay" is over, engine will enter into "Start Idle Delay" (if configured), and after this delay expired, engine will start idle running. Then idle control relay energized and drop speed relay will output. If speed regualtion is configured as relay adjust speed or CAN adjust speed, press raise speed key, idle control relay and drop seed relay will stop output, and speed can be adjusted during idle running.

4) If engine is in idle running, when idle/high speed input is inactive, it will exit idle running and enter into high-speed warming up status and raise speed relay outputs. When "High-speed Warming Up Delay" expired, raise speed relay stops output, and engine enters into normal running. After speed regulation type has been configured, speed can be adjusted in normal running status.

5) While engine is in idle running status, press to end active stop operation, and then engine enters from "Idle Running" to "Stop Idle Delay" (if configured). The remaining stop process is the same as auto stop procedure.

Engine speed control

1) In the "Speed Setting" menu, if you set the speed setting type: "0: Disable", the engine speed setting function will be disabled, and you cannot enter the speed

setting interface by pressing the key;

2) In the "Speed Setting" menu, if you set the type of speed control: "1:CAN Speed

Control - Key", then press key to enter the speed control interface, then press

key to increase speed, press key to decrease speed, and press key to exit the speed control interface and stop speed control. As shown in the figure below:



Note: When the CAN speed control type is set to "1:CAN speed control - key", the engine can be speed controlled at idle or rated operation!

3) In the menu of "Speed Setting", if you set the type of speed control: "2:CAN Speed Control - AUX input", you must set the two switching quantity inputs as **"Speed up "** and **"Speed down"**, and connect the external self-reset switch; press the key to enter the speed control interface, at this time, the engine speeds up when the speed up switch is effective, and the engine speeds down when the speed down

switch is effective. **"Speed up"** and connect the external self-reset switch; press key to enter the speed control interface, at this time, the engine speeds up when the speed up switch is effective, and the engine speeds down when the speed down



switch is effective; press key again to exit the speed control interface and stop speed control.



4) In the "Speed Setting" menu, if you set the type of speed control: "3:CAN speed control-1 or 2", the speed control function of Article 2 and Article 3 above is effective, In the speed control interface, the engine speed can be controlled by the module keys or the external self-reset switch of the AUX input. As shown in the figure below:

Engine speed control
Target speed:1500RPM
Current speed:1499RPM
Increase: /II decrease: /II
Speed control: increasing speed

Note: When the CAN speed control type is set to "3:CAN speed control-1 or 2", the engine can be speed controlled at idle or rated operation!

5) In the "Speed Setting" menu, if you set the speed control type: "4:CAN Speed Control - Potentiometer", you must configure the configurable sensor input as "1: Speed Control Potentiometer", such as Multiple configurable sensor channels are configured as "1: speed potentiometer", then the smallest channel serial number shall prevail; the minimum variable resistance value of external potentiometer is 0-100 Ω ,

and the maximum value is 0-5000 Ω ; press O to enter the speed control interface, and at this time, the controller controls the engine speed according to the resistance value of the potentiometer, and it is "idle speed" when the resistance value is 0. At this time, the controller controls the engine speed according to the resistance value of the potentiometer, when the resistance value is 0, it will be "idle speed", when the resistance value is maximum, it will be "maximum speed value" for the speed control; when the resistance value of the potentiometer is increased, the engine speed increases, and when the resistance value is decreased, the engine speed decreases,

and the controller will exit the speed control interface by pressing the ^(O) key to stop the speed control again.

Please note when setting the CAN speed control type to "4: CAN speed control - potentiometer":

(1) The engine is idling after starting, the speed can only be controlled by potentiometer, the external idle/run switch is invalid!



(2) After the engine is started, when entering the speed control interface for the first time, the resistance value of the potentiometer must be reset to less than 10Ω before the engine speed control can be carried out!

Target speed:1500RPM

Current speed:1499RPM

Potentiometer resistance: 1000Ω

Speed control: increasing speed ...

6) State description of the speed regulation process:

(1) In descending speed: the controller is performing descending control of the engine;

(2) Speed up in progress: the controller is performing speed up control on the engine;
(3) Speed adjustment complete: the controller is completing speed up or speed down control of the engine;

(4) Please reset the potentiometer: after the engine starts, the resistance value of the speed adjustment potentiometer is greater than 10Ω , please rotate it to the minimum position of the potentiometer;

(5) Wait for speed regulation: wait for the operator to carry out speed regulation operation.

♦ Emergency start mode:

In manual mode, pressing the " button and the " button at the same time can force the engine to start. At this time, the controller will no longer automatically judge the successful start condition, and the operator will judge the separation of the starter by himself. The operator observes that the unit has started successfully. After

releasing the "UD" button, the starter motor will be disconnected immediately, and the controller will enter the "safety protection delay" state.

Manual Start Mode

press 🦳 and make sure it is in the stop position before starting.

Press "" and the test file indicator is on. At this time, it is detected whether the connection of each sensor is normal. If the sensor is open, the sensor opens an alarm. If it is normal, the unit start process is executed in the following sequence after

pressing the """. automatically switch to engine provide the power when the unit

is running normally. Press "U" The controller performs the parking process at the following timing:

Manual start and stop process:





Automatic starting mode:

Press 'Stop key , to ensure that the unit is in stop gear before starting. Press 'auto key , the indicator light of auto gear is on, at this time, it will detect whether each sensor is connected normally, if the sensor is open circuit, it will report sensor open circuit alarm, if it is normal, it will wait for the remote start signal to be valid, and then the unit will execute the starting process according to the following time sequence. When the unit enters into normal rated operation, the controller detects that the remote start signal is invalid, and the remote stop input signal is valid, then it will execute the 'loop time delay' and the subsequent shutdown process.

Auto start and stop process:



Notices in Starting Process

Note 1: During the Cranking time, the controller automatically detects the speed signal, oil pressure value or the charging voltage (according to the parameter setting) to reach the judgment condition of successful start, then the judgment is that the start is successful and the motor relay is closed.

Note 2: Within the safety delay, only respond to emergency stop, immediate stop, over speed, ECU communication Failure, other alarms are not responded to.

Note 3: No response to alarm and warning of under speed, low frequency, under voltage, over current, over power,non-balance of current, external instant unloading shutdown,during start idle time.

Note 4: After entering the rated operation, the "rated operation" indicator light is on.

MEBAY

Note 5: In the process of shutdown, if the remote starting signal is restored to be valid within the " Cooling time", the rated operation will be entered again.

Note 6: If the stop key is pressed again during idle time, the idle time will be canceled and the stop operation will be executed directly.

sensor association settings

Fuel level sensor correlation: if need to use fuel level function, one of flexible sensor 1~6 needs to be configured as fuel level sensor, meanwhile, curve type needs to correspond to sensor types. Then set the correlated sensor and select the corresponding flexible sensor. At this time, the flexible sensor is the fuel level sensor, which can realize fuel pump control and tank volume display.

Outlet pressure correlation: if need to calculate flow and head via water pressure gauge, one of flexible sensor 1~6 needs to be configured as outlet press sensor, meanwhile, curve type needs to correspond to sensor types. Then set the correlated sensor and select the corresponding flexible sensor. At this time, flow and head can be calculated via outlet pressure gauge.

Outlet pressure correlation also needs to be configured if E-driven suction pump needs to judge whether to stop the output according to the outlet pressure.

Temperature sensor correlation: If you need to control (heating, cooling, choke) by temperature, one of flexible sensor 1~6 needs to be configured as temperature sensor, meanwhile, curve type needs to correspond to sensor types. Then set the correlated sensor and select the corresponding flexible sensor then you can control (heating, cooling, damper) by temperature.

Commissioning and precautions

1) Ensure all the connections are correct and wires diameter is suitable;

2) Ensure that the controller DC power has fuse, controller's positive and negative connected to start battery are correct;

3) Disconnect the oil valve line and start the engine, the engine group will start to start, after the set number of starts, the controller will send a start failure signal; press the stop button to reset the controller.

4) Turn on the oil valve line and check whether the engine data is normal (speed, water temperature, oil temperature, oil pressure); if everything is normal, the unit will run at idle speed (if it is set to idle speed) to normal operation; if there is any abnormality, Stop the engine unit and check the wiring of each part referring to this manual;

5) Manual shutdown to confirm normal operation.

Warnings and Shutdown Alarms



MEBAY

Notes: Warning is a non-serious failure state, which will not harm the system for the time being. It only reminds operators to pay attention to the situation that does not meet the requirements and solve it in time to ensure the continuous operation of the system. When the warning occurs, the units does not stop. Once the fault is removed, the warning is automatically canceled.

Over Speed Warning

When the controller detects that the engine speed is higher than "**Over speed** warning", Then start warning delay and the duration (Normal warning delay) have not returned to normal, the warning of over speed is reported. "WARN" lights will light up, units will not stop, displays " **Over speed** " on the current fault screen.

Under Speed Warning

When the controller detects that the engine speed is lower than **"Under speed warning**", Then start warning delay and the duration (Normal warning delay) have not returned to normal, the warning of under speed is reported. **"WARN**" lights will light up, units will not stop, displays **"Under speed** " on the current fault screen.

(AUX Sensor 1~6) Warning

When the controller parameter "Sensor alarm Action " is set to "Warning", and the controller detects that the sensor value is lower than "AUX Sensor Warning Threshold", Then start warning delay and the duration have not returned to normal, the "AUX sensor warning" is reported. "WARNING" lights will light up, Generators will not stop, displays "AUX sensor warning " on the current fault screen.

(AUX Sensor 1~6) disconnected warning

When the controller parameter "Action if sensor disconnected" is set to "Warning", When the sensor is detected to be disconnected, Then start warning delay and the duration have not returned to normal, the warning of sensor disconnected warning is reported. "WARNING" lights will light up, Generators will not stop, displays "(AUX Sensor open" on the current fault screen.

External instant warning

When the controller detects that the AUX. Input "External instant warning input" switch is active, it starts warning delay and lasts for input warning delay. When the "External instant warning input" switch is enabled, the warning is reported. "WARN" lights will light up, units will not stop, displays "Instant warn" on the current fault screen.

Speed signal lost warning

When the controller parameter "Action if RPM lost" is set to "warning", the detected speed value is 0, Then start warning delay and the duration (Speed signal lost warning delay) have not returned to normal, the warning of speed signal lost warning is reported. "WARN" lights will light up, units will not stop, displays "Lose speed" on the current fault screen.



Maintenance expiration warning

When the controller parameter "Maintenance expire" is set to "warning", when the maintenance is detected as "0" or maintenance date less than current date, then start warning delay and the duration (Maintenance expire delay), the warning of maintenance expiration is reported. "ALARM" lights on, without stopping the engine, and displays "Maintain end" on the LCD screen.

ECU faults warning

When the controller detects the warning information of ECU, Then start warning delay and the duration have not returned to normal, the warning of ECU faults warning is reported. **"WARN**" lights will light up, units will not stop, displays **"ECU faults warn"** on the current fault screen.

ECU Communication Failure Warning

When the controller parameter "CAN failure" is set to "warning", and controller does not receive any message sent by ECU.It started to delay and lasted for some time, but still did not receive the message from ECU, the warning of ECU faults warning is reported."WARN" lights will light up, units will not stop, displays "ECU comm. fail" on the current fault screen.

Low coolant level switch warning

When the controller detects that the AUX. Input "Low water level warning" switch is active, it starts warning delay and lasts for Input warning delay. When the "Low water level warning" switch is enabled, the engine low coolant level switch warning is reported. "WARN" lights will light up, units will not stop, displays "Low water level" on the current fault screen.

Over battery voltage warning

When the controller detects that the battery voltage is over than the "**Over battery** voltage warning", Then start warning delay and the duration (Over battery warning delay) have not returned to normal, the warning of over battery voltage warning is reported. "WARN" lights will light up, units will not stop, displays "**Over BATT volt**" on the current fault screen.

Under battery voltage warning

When the controller detects that the battery voltage is lower than the "**Under battery** voltage warning", Then start warning delay and the duration (Under battery warning delay) have not returned to normal, the warning of Under battery voltage warning is reported. "WARN" lights will light up, units will not stop, displays "**Under BATT volt**" on the current fault screen.

Charging failure warning

When the gap between D+ and B+ is over than this value, and there is charging failure but still high(Charging failure warning delay), then charge failure warns. **"WARN**" lights will light up, units will not stop, displays **"Charger fault**" on the current fault screen.Once the gap is lower than the value, warns clear.

Starting fault

Fail to Start

If the number of cranks exceeds the predetermined number of cranks, the failure of start-up will be reported if the start-up of the engine unit is still unsuccessful.

"ALARM" lights on, without stopping the engine, and displays " Crank failure " on the current fault screen.

Shutdown Alarms

Warning: After the Shutdown Alarm occurs, the system will be locked

immediately and the unit set will be stopped. Only after troubleshooting, press key to clear the alarm, can it be re-operated.

Notes: When the shutdown alarm failure occurs, the "ALARM" lights will light up and the unit automatically stops.

Over Speed Alarm

When the controller detects that the engine speed is higher than "**Over speed alarm**", Then start alarm delay and the duration (Over speed delay) have not lower than "**Over speed revert**", the alarm of over speed is reported. "**ALARM**" lights will light up, units stops running, and displays "**Over speed** " on the current fault screen.

Under speed alarm

When the controller detects that the engine speed is under than "**Under speed** alarm", Then start alarm delay and the duration (Under speed delay) have not returned to normal, the alarm of under speed is reported. "ALARM" lights flicker, engine stops running, and displays "**Under speed** " on the current fault screen.

(AUX Sensor 1~6) Alarm

When the controller parameter "Sensor alarm Action " is set to "Alarm", and the controller detects that the sensor value is lower than "Alarm Threshold", Then start alarm delay and the duration have not returned to normal, the "AUX sensor alarm" is reported. "ALARM" lights will light up, Generators stops running, displays "AUX sensor Alarm " on the current fault screen.

(AUX Sensor 1~6) disconnected Alarm

When the controller parameter "Action if sensor disconnected" is set to "Alarm", and the sensor is detected to be disconnected, Then start alarm delay and the duration have not returned to normal, the alarm of sensor disconnected alarm is reported. "ALARM" lights will light up, Generators stops running, displays "(AUX Sensor open" on the current fault screen.

High coolant temperature switch alarm

When the controller detects that the AUX. Input port "High coolant temperature alarm switch" switch is active. Start low oil pressure switch alarm delay, for a period of time "Input alarm delay" AUX. Input port "High coolant temperature alarm switch" is valid. Then the alarm, the public alarm light "ALARM" lights will light up, stop the units operation, and display "High WT switch" on the current fault screen.

Low fuel level switch alarm

When the controller detects that the AUX. Input "Low fuel level alarm input" switch is active, it starts alarm delay and lasts for Input alarm delay. When the "Low fuel level alarm input" switch is enabled, the engine low fuel level switch alarm is

reported. "ALARM" lights will light up, units stops running, and displays "Low fuel level switch" on the current fault screen.

External instant alarm

When the controller detects that the "**External instant alarm input**" switch of the AUX. Input port is valid, the external instant trip is started and the shutdown alarm delay is delayed for a period of time "**Input alarm delay**" AUX. Input port "**External instant alarm input**" switch When it is valid, it will alarm, the public alarm light "**ALARM**" lights will light up, units stops running, and display "**Instant parking**" on the current fault screen.

Speed signal lost alarm

When the controller parameter "Action if **RPM lost**" is set to "alarm", the detected speed value is 0,Then start alarm delay and the duration (Speed signal lost alarm delay) have not returned to normal, the alarm of speed signal lost warning is reported. "ALARM" lights will light up, units stops running, displays "Lose speed" on the current fault screen.

Maintenance expiration alarm

When the controller parameter "**Maintenance expire**" is set to "**alarm**", when the countdown to maintenance is detected as "0" or maintenance date less than current date, then start alarm delay and the duration (Maintenance expiration delay), the alarm of maintenance expiration is reported. "**ALARM**" lights on, without stopping the engine, and displays "**Maintain end**" on the LCD screen.

ECU faults alarm

When the controller detects the alarm information of ECU, Then start alarm delay and the duration have not returned to normal, the alarm of ECU faults alarm is reported. "ALARM" lights will light up, units stops running, displays "ECU faults warn" on the current fault screen.

ECU communication failure alarm

When the controller parameter "CAN failure" is set to "alarm", and controller does not receive any message sent by ECU.It started to delay and lasted for some time, but still did not receive the message from ECU, the alarm of ECU faults alarm is reported."ALARM" lights will light up, units stops running, displays "ECU comm. fail" on the current fault screen.

Low coolant level switch alarm

When the controller detects that the AUX. Input "Low water level alarm" switch is active, it starts alarm delay and lasts for Input alarm delay. When the "Low water level alarm" switch is enabled, the engine low coolant level switch alarm is reported. "ALARM" lights will light up, units stops running, displays "Low water level" on the current fault screen.

Louver opening exception alarm

When the controller detects that the AUX. input "Louver status input" switch is active, it starts alarm delay and lasts for Input alarm delay. When the "Louver status input" switch is enabled, the Louver status input alarm is reported. "ALARM" lights will light up, engine stops running, displays "Louver abnormal" on the current fault screen.



Emergency stop alarm

When the controller detects that the AUX. Input "**Emergency stop**" switch is active, it starts alarm delay and lasts for Input alarm delay. When the "**Emergency stop** alarm" switch is enabled, the engine Emergency stop alarm is reported. "**ALARM**" lights will light up, units stops running, displays "**Emergency stop**" on the current fault screen.

Stop failure with speed alarm

When the controller detects that the speed is not "0" after the execution of the shutdown, the alarm of stop failure is reported. "ALARM" lights will light up and displays "Stop fail-RPM" on the current fault screen.

Stop failure with pressure alarm

When the controller detects that the Oil **Pressure** is not "0" after the execution of the shutdown, the alarm of stop failure is reported. "**ALARM**" lights will light up and displays " **Stop fail-OP-A** " on the current fault screen.

Parameter setting

Enter the edition page

Please set the parameters according to below steps:

1) The setting mode can be active after pressing und simultaneously,

under the status of standby without any alarm. The default password is "07623".

2)Press 🌥 and add number 1, press 🍸 to reduce number 1, press 呸 to turn

the digit into right, press once done. Then system comes into menu after confirmation of password setting. The screen will display error if password is wrong. The correct password should be put after pressing any button.

3)Press \frown to turn the digit into upper position, press \heartsuit to turn the digit into

lower position, press or to get into parameters setting page.

4) Press \bigtriangleup to shift up the parameters, press \blacktriangledown to shift down the parameters,

press of to get into parameter changing page.

5)Press \frown to add number 1, press \checkmark to reduce number 1, press \odot to turn

the digit into right, press once done. If the parameters setting is in the valid setting range, then it can be saved, if not, it can not be saved.

6)Press 🥙 and 🛄 to save the parameters and exit from edition page.

7) Press U to revert back to last class if in any setting position.



 ${
m L}_{
m Note:}$ the data can't be saved if the user didn't press ${
m ullet}$ to confirm the setting.



♦ Parameter list.

0) Language settings

No	Parameter	Range(defaults)	Notes
1	Language	0-English 1-简体中文 2-繁体中文 3-Русский 4-Espanol 5-Türk dili 6-Français 7-Românesc 8-Polski 9-Português 10-Deutsch 11-한국어 12-Tiếng Việt 13-بالعربية- 14-Bahasa Indonesia 15	Language option. Display language selection. 0: English, 1: Simplified Chinese, 2: Traditional Chinese, 3: Spanish, 4: Russian, 5: Turkish, 6: French, 7: Romanian, 8: Polish, 9: Portuguese, 10: German, 11: Korean, 12: Vietnamese,13:Arabic,14: Bahasa Indonesia,15:Persian.

1) Override Mode

• • •	e ternae meat	•	
No	Parameter	Range(defaults)	Notes
1	Ovorrido Modo	0: Disable	All shutdown alarm quantities are disabled except
I		1: Enable	emergency shutdown and overspeed.

2) Delay time setting

No	Parameter	Range <i>(default)</i>	Notes
1	Start delay	0-6500.0s (5.0s)	The time during the engine starts after the remote signal is valid.
2	Return Delay	0-6500.0s (5.0s)	The time during deactivated to engine stop, after the remote signal is valid.
3	Preheat time	0-6500.0s (0.0s)	The time needed to be preheated before the starter on power.
4	Fuel output delay	0-6500.0s (2.0s)	The time the fuel valve relay outputs before the motor operates.
5	Cranking time	3.0-60.0s (8.0s)	Time of starter power up.
6	Crank rest time	3.0-60.0s (10.0s)	The waiting time before second power up when engine starts fail.(If diesel driven suction pump enabled, it is also can be crank rest time of diesel driven suction pump).
7	Safety delay	0-6500.0s (8.0s)	Low oil pressure, high water temperature, under speed, under frequency, under voltage, charge failure are all invalid during this time except for emergency stop and over speed.
8	Start idle time	0-6500.0s (5.0s)	Idle running time when crank



			successfully.
9	Warming-up time	0-6500.0s (10.0s)	The time needed for loading.
10	Cooling time	0-6500.0s (30.0s)	After unloading, the time of cooling down by radiator before stop. during the delay, if the remote start signal is valid, then engine will come into rated
			running.
11	Stop idle time	0-6500.0s (5.0s)	Idle-speed running time.
12	E.T.S. hold time	0-6500.0s (10.0s)	Stop solenoid on power time.
13	Fail to stop	0-6500.0s (30.0s)	If the RPM is 0 during the stop failure time, then the stop failure time is no needed.
14	Input alarm delay	1.0-60.0s (5.0s)	The alarm delay except for Aux.input.
15	Input warning delay	1.0-60.0s (2.0s)	The Aux.input warning delay.
16	Pulse speed up delay	0.1-60.0s (0.2s)	The interval time of the pulse speed up relay change.
17	Pulse speed down delay	0.1-60.0s (0.2s)	The interval time of the pulse speed down relay change.

3) Engine setting

NO	Parameter	Range(<i>default</i>)	Notes
	CAN Protocol	0- Disabled	CAN protocol Option: the Engine
		1: J1939	parameters like RPM, oil pressur
		2: Cummins ISB	e, water temperature are all from
		3: Cummins-CM850	ECU data after choosing the relat
		4: Cummins QSX15-CM570	ive protocol.
		5: Cummins-CM850-PCC13X	
		6: Cummins-DCEC-QSZ13	
		7: Cummins-CCEC-QSN	
		8: Perkins	
		9: Perkins-1100	
		10: Volvo	
		11: Volvo-EMS2	
		12: Volvo-EMS2b	
1		13: Volvo-EDC4	
·		14: Scania	
		15: Scania-kw2000	
		16: Scania-kw2k-coo	
		17: John Deere	
		18: mtu-ADEC	
		19: mtu-ADEC-SAM	
		20: mtu-ADEC-303	
		21: mtu-ADEC-304	
		22: BOSCH	
		23: GISC1	
		24: MISC1	
		25: YUCHAI-YCECU	
		26: Y&C ENGINE-YC6K	
1		27: WEICHAI-WISE15	



		28: CHANGCHA	AI-ECU15	
		29: YUCHAI-LM	В	
		30: MAN		
		31: J1939-C		
		32: SDEC-H/D		
		33: SDEC-E		
			20.0004	
			KZ-ZUUT	
		30. DEUTZ EMP	KZ-ZUTZ	
		37. DEUTZ EMP		
			113	
		40°Cummins-CA	/2150	
			12100	When used in gensets: Some
				CAN protocols need to send a
	Rated	40.0-80.0Hz		rated frequency setting command
2	frequency	(50.0Hz)		to be converted into speed: e.g.
		, ,		Cummins-CM850, Volvo-EMS2,
				etc.
		Speed type	0: Speed sensor	If the setting is 0 (RPM sensor
			1: W/L	Disabled).
		Flywheel teeth	0-300 (118)	
	Rotation speed setting	Rated RPM	500-4500RPM	Choose the meter range and
			(1500)	calculate the alarm value.
			warning	The number of the flywheel teeth
3		IOSI	Alarm and stop	is not 0 before checking the
		Loss of Speed Signal	0-3600.0s (5.0s)	speed loss action.
		Rated idle	500-4500rpm	ECU idle speed value.
		speed	(750rpm)	
		Slow rise time	0-120.0S (5.0S)	The time of ECU from idling to high speed.
		Alarm value	0-200% (114%)	Sets the engine rated speed
		Return value	0-200% (110%)	percentage. Disables the engine
		Alarm action	0: Warning	over speed alarm when set to
4	Engine over	Alamiaction	1: Alarm and stop	200 St. In speed control mode
	speed setting			the over speed alarm value is the
		Alarm delay	0-3600.0s (2.0s)	target speed * over speed alarm
				percentage
		Alarm value	0-200%(80%)	Sets the engine rated speed
		Return value	0-200%(85%)	percentage. Disables the engine
		A. 11	0: Warning	under speed alarm when the set
5	Engine under	Alarm action	1: Alarm and stop	
Ŭ	speed setting		•	
		Alarm delay	0-3600.0S(3.0S)	mode, the under speed alarm
				value is the target speed under
			8 0-36 0\/	When the battery voltage is lower
6	Battery setting	Rated voltage	(24 0V)	than start value and remains 10e
		Charging start	8 0-30 0 (25 6\/)	under non-running status then
1	1	Lonarging start	10.0 00.0 20.0 V	



		Charging stop Over battery Under battery	10.0-36.0 (27.8V) 0-200%(135%) 0-200%(67%)	the relay is opened. When it is higher than the close value and remains 10s, relay is closed. Once coming into running mode, there is no output. Sets the percentage of rated battery voltage. Disables the
		Warning delay	0-3600.0S (60.0S)	battery over voltage warning when set to 200. Disables the battery under voltage warning when the set value is 0.
		Charger warning Charger warning delay	1.0-30.0V (30.0V) 0-3600.0s (10.0s)	Detects D+ and B+ when their difference, and disables the charge failure warning when set to 30.
7	Local start crank times	1-30 (1 time)	Crank times under I suction pump enabl attempts of diesel d	ocal start mode.(If diesel driven ed, it is also can be crank riven suction pump).
8	Auto start crank times	1-30 (3 times)	Crank times under auto mode.(If diesel driven suction pump enabled, it is also can be crank attempts of diesel driven suction pump).	
9	E.T.S. hold times	1-10 (2 times)	The max E.T.S. hold stop success under time is " Fail to stop	d on power shall be canceled once auto mode. the output interval ".
10	Crank disconnect	RPM Oil pressure <i>RPM/Oil</i> <i>Pressure</i>	1.If there is no oil pr choose the type. 2.Oil pressure switc 3.Please check if th are according with o 4.Means either of th crank condition. But together to regard a	essure sensor, please don't h input is not the crank condition e running status, stop condition crank condition. e conditions can be acceptable as all of them should be meet s stop condition.
11	Crank disconnect conditions	RPM disconnect Oil pressure disconnect Oil pressure delay	0-200% (24%) 0-400kpa (200kpa) 0-60.0s (0.0s)	According to the judgement of starting success conditions, the judgement conditions are met, the starting is considered successful, and the crank disconnect.
12	Pre-oil supply setting	Pre-oil supply rest Time	0-12h (0.0h)	When output is configured as "Pre-oil supply", it is the interval between the completion of the pre-fuel supply output and the next Pre-oil supply output in standby status. If time is 0,Pre-oil supply is not output in standby status. It is Pre-oil supply output time
		output time	3—30.0s (5.0s)	when output configured as "Pre- oil supply".



4) Suction Pump setting

No	Parameter	Range(defaults)	Notes
1	Suction pump crank	<i>0: Disable</i> 1: D-driven suction pump 2: E-driven suction pump	Select whether to start the suction pump and pump type.
2	D-driven suction pump fault shutdown delay	0-3600.0S (90.0S)	Time for waiting press to suction pump ("Waiting Press. to" input is active).
3	D-driven suction pump crank output time	0-3600.0S (5.0S)	Time for D-driven suction pump crank output.
4	D-driven suction pump stop output time	0-3600.0S (15.0S)	Time for D-driven suction pump stop output.
5	Outlet press when E- driven suction pump stopped	0-1000kpa (100kpa)	It is pressure when "E-driven Pump Start" input stops outputting.

5) Sensor setting

No	Parameters	Range(c	lefaults)	Notes
		Lisers Configured	Water	
		name	Temperature	
	AUX.SENSOR 1 AUX.SENSOR 2	name	Sensor	
		Sensor Type	1: Temperature	
			type sensor	
		Signal Type	1: Resistive type	
		Display Unit	1: °C	
		Curve Type	2:VDO 40-120 °C	Deleted Settings Disease refer
1	AUX.SENSOR	Lower range limit		Related Settings Please refer
	1	Upper range limit		Conorality Sottings
		Sensor Disconnect	1: Warning	
	AUX.SENSOR 1 AUX.SENSOR 2	Action	r. warning	
		Alarm Action	2:Alarm and stop	
		High Alarm value	98 C	
		Low Alarm Value		
		Alarm Action Delay	5.0S	
		Users configured		
		curve setting		
		Users Configured	Oil Pressure	
		name	Sensor	
		Sensor Type	2: Pressure type	
			sensor	
		Signal Type	1: Resistive type	
	AUX SENSOR	Display Unit	2:kPa	
2	2	Curve Type	2:VDO 0-10Bar	Related Settings Please refer
	2	Lower range limit		to User Configurable Sensor
		Upper range limit		Generality Settings
		Sensor Disconnect	1: Warning	
		Action		
		Alarm Action	2:Alarm and stop	
		High Alarm Value		



				-	
		Low Alarm Value	103kPa		
		Alarm Action Delay	5.0S		
		Users configured			
		curve setting			
3	AUX.SENSOR	3	Disable	Related Settings Plagss refer	
4	AUX.SENSOR	4	Disable	to User Configurable Sensor	
5	AUX.SENSOR	5	Disable	Generality Settings	
6	AUX.SENSOR	6	Disable		
		Open Value	-50℃-300℃ (-50℃)	Heating Control Sotting	
		Close Value	-50℃-300℃ (-50℃)	Minimum Disable	
7	Heating	Maximum time	0-7200Min (0Min)		
ľ	Settings	Associated		Associated Temperature	
		connection	AUX.SENSOR1~6	Sensor Valid	
		Sensors			
		Open Value	-50℃-300℃ (-50℃)	Cooling Control Setting	
		Close Value	-50℃-300℃ (-50℃)	Minimum Disable	
8	Cooling	Maximum time	0-7200Min (0Min)		
	Settings	Associated		Associated Temperature	
		connection	AUX.SENSOR1~6	Sensor Valid	
		Sensors	0.4000/ (050()	T I ()	
		Open Value	0-100% (25%)	I he fuel pump switches on	
		Close value	0-100% (80%)	the act value and lasts for 10a	
		Maximum fuel pump on time	0-65000s (0s)	The fuel pump switches off	
				when it is higher than the set	
				value and lasts 1s. Time	
				minimum 0 disables the fuel	
				pump output function.	
9	setting	Filling detection	0-600s (30S)	When the fuel pump is	
	ootang			operating, if an increase in the	
		-	0-10000L <i>(0L)</i>	sensor fuel level value of less	
		Tank volume		than 3% is detected during this	
				time, a fuel filler system fault	
		Accoriated		warning is reported.	
		connection	ALLY SENSOR1~6	Associated Fuel Sensor Valid	
		Sensors	AUX.SENSOR 120		
			0: Disable		
		Pump head	1: Enable		
		D	0: Disable		
		Pump llow	1: Enable		
		Static pressure	-10000-10000kpa	Setting static pressure of water	
10			(0kpa)	pump outlet port.	
10	Outlet	Rated flow	0-10000 m³/h	Rated working flow of engine.	
	Pressure		(1000m³/h)	<u> </u>	
	setting	Flow unit	U: M³/N		
			1. L/S	Warning if flow value is higher	
		Over flow Warn	0-200% (110%)	than this value during engine	



	1					
				running. Enable alarms, delay		
				value and return value can be		
				Sel.		
		Over flow		bigher than this value during		
		shutdown	0-200% (120%)	engine running. Enable alarms		
				and delay value can be set.		
				Set the relationship between		
		Flow Curve Set		the different outlet pressures		
				and its corresponding flows.		
		Associated		Associated Outlet Pressure		
		connection	AUX.SENSOR1~6	Sensor Valid		
		Sensors				
		Chaka alaaing		Used to control the choke,		
		temperature	20–200°C (40 °C)	engine temperature falls below		
		Chiperature		this setting.		
11	Choke setting	Choke closing				
	5	delay	0—200.0s (3.0s)	Choke closing delay time.		
		Associated		Associated Temperature		
		connection	AUX.SENSOR1~6	Sensor Valid		
		Sensors				
		User Configurabl	e Sensor Generalit	y Settings		
		0: Disable ; 1: Users Configured sensor name; 2: Potentiometer;				
		6: Fuel level sensor	7. Pine Network nr			
		8. Inlet pressure sensor: 9. Outlet pressure sensor				
Use	ers Configured	10: Torque converter oil temperature sensor: 11: Water level sensor:				
nar	ne	12: water pressure sensor; 13: Coolant temperature sensor;				
		12: Exhaust gas temperature sensor; 13: Exhaust gas pressure sensor;				
		14: Intake pressure sensor; 15: Primary pressure sensor;				
		16: Secondary pressure sensor; 17: System pressure sensor;				
		18: Flow sensor.				
		0: Disable				
501	nsor Type	1: Iemperature type sensor				
	isor rype	3. Percentage sensor				
		4: Flow rate type				
		1: Resistive type				
Sig	nal Type	2: Voltage type				
		3: Current type				
		Resistive type	1:℃ 2:°F			
Display Unit		Voltage type	1:Bar 2:kPa 3:	PSI 4:MPa		
		Current type	1:%			
		Flow rate type	1: m³/h 2: L/s			
				1:Users Configured Resistive		
C						
Curve Type		Posistivo turo	Proseuro turo	$2 \times 100 \text{ m}$		
Cu	rve Type	Resistive type	Pressure type	2:VDO 0-10Bar 3:MEBAY-003B		



		5:SGD
		6:SGX
		7:CURTIS
		8:DATCON 10Bar
		9.VOLVO-EC
		10:3015237
		12.GENCON 0-10Bai
		TOSers Conligured Resistive
		Temperature Sensor
		2:VDO 40-120℃
		3:MEBAY-001B
		4:MEBAY-Mier
		5:SGH
		6:SGD
	Temperature type	7'SGX
	remperature type	8.CURTIS
		12:2015238
		12.0010200 10.DT100
		13:WEICHAI 40-120°C
		14:GENCON 40-120℃
		1:Users Configured Resistive
		Percentage Sensor
		2:0-100Ω
		3:100-0Ω
		4:0-107Ω
		5:107-0Ω
		6:0-180Ω
		7:180-00
		8.10-1800
		9.180-100
		10.10-1200
	Percentage	11.120-100
	r crocinayc	12.0-900
		13.00-00
		14:0-300
		15:30.00
		10.00-012
		10. / 3-1002
		17:240-3302
		18:33-100Ω
		19:0-200Ω
		20:200-0Ω
		21: 0-190Ω
		22: 190Ω-0Ω
	1: Users Configure	ed voltage type
Voltage type	2: 0-5V	
	3: 0.5-4.5V	
Current type	1: Users Configure	ed current type



		2: 4-20mA	
	Pressure type sensor	0-60MPa	
	Temperature type	lower limit	-100 - 1000℃
Range limit setting	sensor	upper limit	-100 - 1000℃
	Doroontago concor	lower limit	0-200%
	Percentage sensor	upper limit	5-200%
	Flow rate type	0 - 6000m³/h	
Sensor Disconnect Action	1:Disable 2:W	/arning 3:Alarn	n and stop
Alarm Action	1: Warning 2:Alar	m and stop 3:Stop	after heat dissipation
High Alarm Value	0 - 6000		
Low Alarm Value	0 - 6000		
Alarm Action Delay	0 - 6000s		
Users configured curve setting	Sensor curve can be Users Configured by panel buttons, red resistance and according value should be input,MAX 15 groups ,MIN 2 groups. Bule: resistance should be input from small to large		

6) Input setting

No	Parameters	Rang	ge (defaults)	Notes
1	AUX. INPUT 1 (Pin19	9)	13.Emergency shut	down
2	AUX. INPUT 2 (Pin20))	29:Remote start	
3	AUX. INPUT 3 (Pin21)	4:High water tempe	rature alarm switch
4	AUX. INPUT 4 (Pin22	<u>2)</u>	2:Low oil pressure	alarm switch
5	AUX. INPUT 5 (Pin23	3)	0:Disable	
6	AUX. INPUT 6 (Pin24	4)	0:Disable	
		Function	0-50	Fixed projects: Only fixed
		Valid Type	Normal close	functions and valid
		valid Type	Normal open	methods can be selected
		Action	Warning	
			Alarm	
7	AUX INPUT setting	K. INPUT setting	Disable	Users Configured
1			Standby	projects: All options can be
		Point	From crank	set when valid when
			From safety on	(Function 1: Users
			After rated running	Configured).is selected.
			Always	
		Delay	0-3600S	
		AUX. in	put function table	

0.Disable.

1.Users Configured.

2.Low oil pressure alarm. 3.Low oil pressure warning.

4.High water temperature alarm. 5.High water temperature warning.

6.Low water level alarm.

- 7.Low water level warning.
- 8.Low fuel level alarm.
- 9.Low fuel level warning.
- **10.Lamp Test:** When the input is valid: the indicator lights are all on.
- 11. Louver status input.
- 12.Meter mode: all output are disabled, alarm and warns are invalid.
- 13.Emergency stop.
- 14.Reset Alarm: Can reset shutdown alarm when input is active.
- 15.Silent alarm: audio alarm output is disabled if there is signal output.
- 16.External instant warning.
- 17.External instant alarm.
- 18.Reserved.
- 19.Reserved.
- 20.Reserved.
- **21.Panel lock:** any button except for page button is disabled if there is signal output.
- **22.Auto stop inhibit:** In auto mode, during engine normal running, when input is active, inhibit engine shutdown automatically.
- **23.Auto start inhibit:** In auto mode, inhibit engine start automatically when input is active.
- 24.Scheduled run inhibit: In auto mode, inhibit scheduled run engine when input is active.
- **25.Crank success input:** When this function is active, it means the engine is started successfully. If this function is configured, the speed and oil pressure crank success conditions will be invalid.
- **26.Idle/High speed:** Enter into idle mode when input is active; return back to high-speed running when input is inactive.
- 27.Idle/High Speed (Manual): In auto mode, it doesn't return back to idle mode when input is active; In manual mode, it enters idle mode when input is active; return back to highspeed running when input is inactive.
- **28.Idle/High speed (Memory):** In the normal running, it enters idle mode when input is active; return back to last adjusted high-speed value when input is inactive. It is only active for the current start and still run to rated speed for next start.
- 29.Remote start: In auto mode, when input is active, engine can be started automatically.
- **30.Remote stop:** In auto mode, when input is active and remote start input is inactive, engine can be stopped automatically.
- **31.Manual Start Input:** In auto mode, when input is active, engine can be started automatically; when input is inactive, engine can be stopped automatically.
- **32.Simulate Stop key:** An external button (unlatched) can be connected and pressed as simulate panel.
- **33.Simulate Manual key:** An external button (unlatched) can be connected and pressed as simulate panel.
- **34.Simulate Auto key:** An external button (unlatched) can be connected and pressed as simulate panel.
- **35.Simulate Start key:** An external button (unlatched) can be connected and pressed as simulate panel.
- **36.Simulate Speed Regulation key:** An external button (unlatched) can be connected and pressed as simulate panel.
- **37.Reset maintenance time:** Controller will set maintenance time and date as default when input is active.
- 38.External charging failure: When input is active, charging failure warning alarm occurs.
- 39.Speed up: When the input is valid: the speed increases according to the set acceleration step;
- **40.Speed down:** When the input is valid: the speed decelerate according to the set

deceleration step;

- **41.D-driven suction pump started:** When input port is active, it indicates diesel driven suction pump started successfully.
- **42.Press. to suction pump:** When input port is active, it indicates pressure has been to suction pump.
- 43.Water gun On/Off input: (1,Normal status: if input is active, bypass control is output between start idle to stop idle period.)(2, Idle running status: if input is active, engine operates idle running to normal running, meanwhile, bypass control starts output (if configured).
- **44.High water level input:** In auto mode, when input is active, engine can be started automatically (drain flood).
- **45.Low water level input:** In auto mode, when input is active and high water level input is inactive, engine can be stopped automatically (drain flood)
- 46.-50 Reserved.

	i / output ootting					
No	Parameters		Range (defaults)	Notes		
		Function	0-80(24:Fuel output)	Set the default value		
1	1 (Pin5)		0-Normal open	(please refer to the AUX.		
		valiu Type	1-Normal close	Output function table)		
		Function	0-80(13:Public warning			
2	AUX.OUTPUT	Function	output)	Set the state when the		
2	2 (Pin7)	Valid Type	0-Normal open	AUX. output is valid.		
		valid Type	1-Normal close			
	AUX.OUTPUT 3 (Pin8)	Function	0-80(14:Public alarm output)			
3		3 (Pin8) Valid Type	0-Normal open			
			1-Normal close			
	AUX.OUTPUT 4 (Pin9)	Function	0-80(34:E.S.T. hold)			
4			0-Normal open			
		valid Type	1-Normal close			
		Function	0-80 (0:Disable)			
5	5 (Pin10,11) Valid Type 0-Normal 1-Normal	0-Normal open				
		Valid Type 1-Normal close	1-Normal close			
		Function	0-80 (0:Disable)			
6	A0A.001F01 6 (Pin12 13 14)	Valid Type	0-Normal open			
	o (Fii12, 13, 14) Valid Type	valid Type	1-Normal close			
	AUX. Output function table					

7) Output setting

0.Disable

1.Input 1 valid: Action when input 1 is valid.

- 2.Input 2 valid: Action when input 2 is valid.
- 3.Input 3 valid: Action when input 3 is valid.
- 4.Input 4 valid: Action when input 4 is valid.
- 5.Input 5 valid: Action when input 5 is valid.
- 6.Input 6 valid: Action when input 6 is valid.
- **7.Associated connection AUX.SENSOR 1 :** The association can users configured outputs of sensor 1 (Disconnect, warning, alarm, etc.).
- **8.Associated connection AUX.SENSOR 2**: The association can users configured outputs of sensor 2 (Disconnect, warning, alarm, etc.).
- **9.Associated connection AUX.SENSOR 3 :** The association can users configured outputs of sensor 3 (Disconnect, warning, alarm, etc.).



- **10.Associated connection AUX.SENSOR 4 :** The association can users configured outputs of sensor 4 (Disconnect, warning, alarm, etc.).
- **11.Associated connection AUX.SENSOR 5**: The association can users configured outputs of sensor 5 (Disconnect, warning, alarm, etc.).
- **12.Associated connection AUX.SENSOR 6 :** The association can users configured outputs of sensor 6 (Disconnect, warning, alarm, etc.).
- 13.Public warning output: when there is any warning output.
- **14.Public alarm output:** Action when engine common warning, common shutdown, common trips alarm.
- 15.Audio alarm: when there is any alarm output, the Audio controls.
- 16.Lamp Test Output: Output when lamp test is in progress.
- 17.Preheat mode 1: preheat before start.
- 18.Preheat mode 2: preheat before crank success.
- **19.Preheat mode 3:** preheat after safety delay.
- **20.Louver control:** Outputs when the engine is switched on, and stops when the engine is stopped.
- 21.Choke control: choke will be started after crank success and off after delay.
- **22.Fuel Pre-supply Output:** 1)In standby status, "Fuel Pre-supply" output is active, it will cycle output based on the pre-set "Fuel Pre-supply Rest Time" and "Fuel Pre-supply Time"; if "Fuel Pre-supply Rest Time" is set as 0h, it will not output. 2)"Fuel Pre-supply Time" is outputting before starting. If the pre-heat time is not configured, the fuel pre-supply phase outputs; if pre-heat time is configured, the preheat phase outputs.
- **23.Oil Pre-lubrication output:** Action in period of pre-heating, cranking and crank rest time.
- 24.Fuel output: output once engine starts and off till stable.
- 25.Crank output: output once cranking, no output in other mode.
- 26.Crank Success Output: Close when detects crank success signal.
- **27.Engine block running:** output under running, off once RPM is lower than cranking RPM. The crank success condition can be set.
- **28.Idle speed control:** used for speed controller, there is output under idle but no output under high speed.
- 29.Speed-up control: there is output when coming into high speed warming up, which time is Longest RPM-up time.
- **30.High speed control:** The output is valid after idle delay is completed, and the output is closed after high-speed heat dissipation.
- **31.Speed-down control:** the output time is shutdown idle delay during shutdown idle or shutdown on power procession.
- **32.Pulse speed up output:** the pulse shall be sent out in the interval of "Pulse speed up delay" under speed –up.
- **33.Pulse speed down output:** the pulse shall be sent out in the interval of "Pulse speed down delay" under stop idle speed.
- **34.E.S.T. hold:** shutdown output, it is used for engine with stop solenoid. when the setting value of shutdown delay is over, then it is off.
- 35.Reserved.
- 36.Rated running: there is output under rated running.
- 37.Heating output: output according to the heating condition setting;
- 38.Cooling output: output according to the cooling condition setting;
- 39.Fuel pump output: output according to fuel pump setting conditions;
- **40.Oil pump control:** when the CAN protocol is Yuchai LMB. When the engine is in the standby state, the oil pump controls the output every 30 minutes. If the oil pressure is higher than 100kPa or the output is 1 minute (whichever comes first), the oil pump

control output will stop; when the engine is in the preheating state, the oil pump control will always output.

- **41.Battery charging control:** there is output if the voltage is lower than the preset value under standby status and shutdown after start and in running status.
- 42.System in stop: there is output under stop mode.
- 43.System in manual: there is output under manual mode.
- 44.System in auto: there is output under auto mode.
- 45.Override output: The controller output when it is in Override mode.
- **46.ECU power:** apply to electrical ECU engine, used for control ECU power.
- 47.ECU stop: apply to electrical ECU engine, used for control ECU shutdown.
- 48.ECU warning: there is a warn signal from ECU.
- 49.ECU alarm: there is an alarm signal from ECU.
- 50.ECU communication failure alarm: Cannot communicate with ECU.

51.Reserved.

- 52.ECU communication failure warning: Output when ECU Communication Failure Warning.
- 53.Fail to start alarm: Output when the engine fails to start.
- 54.Stop failure alarm: Output when the engine shutdown fails to alarm.
- 55.Under battery voltage warning output :Output when the battery voltage is low warning.
- **56.Over battery voltage warning:**Output when the battery voltage is low warning.
- 57.Charging failure warning:Output when the engine charger fails to charge.
- **58.Floating charger fault warning:**Output when the floating charger fails to charge.
- 59.Emergency stop alarm: Output when emergency stop alarm.
- 60.Over speed warning: Output when Over Speed Warning.
- 61.Over speed alarm: Output when Over Speed alarms.
- 62.Under speed warning: Output when engine under speed warning.
- 63.Under speed alarm: Output when engine under speed alarm.
- **64.D-driven Pump Start:** Output when suction pump set as diesel-driven suction pump.
- 65.D-driven Pump Stop: Output when suction pump set as diesel-driven suction pump.
- 66.E-driven Pump Start: Output when suction pump set as electronic-driven suction pump. It stops output when engine stopped.
- 67.Bypass Control Output: The input port is configured as "Water Gun On/Off Status Input" and is output between the "Start Idle" and "Stop Idle" when input is active.
- 68.Over Flow Shutdown: Action when engine over flow shutdown alarm occurs.
- 69.Over Flow Warning: Action when engine over flow warning alarm occurs.

70.-100 Reserved.

8) CAN communication		
No	Parameter	Range(<i>default</i>)	Notes
1	ECU failure	Disable Warning Alarm and Stop	ECU communication failure.
2	ECU warning	Disable/ Enable	ECU warnings enable.
3	ECU alarm	Disable/ <i>Enable</i>	ECU alarms enable.
4	Mask SPN	0-12	Up to 12 sets of alarm codes can be input, and the controller will not respond to the input alarm codes.
5	ECU speed control address	0-255 (3)	The TSC1 message ID address sent by the controller to the ECU, and the



			communication protocol must be 31: J1939-C.
6	CAN communication rate	0-Automatic detection 1-125Kbps 2-250Kbps 3-500Kbps	CAN communication rate
7	Low oil pressure Alarm from ECU	0-999kpa (103kpa)	When the oil pressure data comes to the ECU, set the low oil pressure alarm value.
8	Coolant temperature high alarm from ECU	20-200℃ (98<i>℃</i>)	When the Coolant temperature data comes to the ECU, set the coolant temperature high alarm value.

9) Adjust Speed Setting

No	Parameter	Range(<i>default</i>)		Notes
1	Speed control type	0:Disable 1:CAN speed cor 2:CAN speed-swi 3:CAN speed - 1 4:CAN speed - po	ntrol-keypad itching or 2 otentiometer	Selecting the speed control method.
2	Maximum speed	500-4500RPM (2500RPM)	Sets the maxin control.	num speed for the engine speed
3	Speed up step	1-200RPM (50RPM)	Sets the step of key is pressed amount is actu	f speed increase when the once or the acceleration switching ated once.
4	Speed down step	1-200RPM (50RPM)	Set the step size the key i deceleration sy	ze of the speed reduction when s pressed once or the vitching volume is actuated once.
5	Potentiometer resistance	100-5000Ω (4700Ω)	Set the resistar potentiometer; engine speed f value" to "maxi	nce value of the external speed the potentiometer adjusts the from "electronically controlled idle mum speed value".

A)Module settings

		<u>j</u>	
No	Parameter	Range(defaults)	Notes
1	Host and slave mode	0: Host mode 1: Slave mode	Select the instrument communication mode, the slave can read and display the parameters of the host through the RS485 port.
2	User password	00000-65535 (07623)	Change the password.
3	Controller ID	1-255 (16)	The IP built by controller and PC.
4	RS485 baud rate	0-4800 1-9600 2-19200 3-38400 4-57600 5-115200	RS485 communication baud rate.
5	Start screen display time	0-20.0s (5.0s)	Start screen display time,0: No-display.



6	LCD contrast	50-127 (106)	Set the LCD display contrast.
7	Saving mode	5.0-6000.0s (600.0s)	LCD light will be closed automatically without any button pressed after delay. If setting as 6000.0s, back light always lighted.
8	Homing display	5.0-600.0s (600.0s)	The time when the page reverts back to the home page. If setting as 600.0s: disabled.
9	LOGO delay display under standby	5.0-6000.0 (6000.0s)	Start screen will be opened without any button pressed after delay. If setting as 6000.0s: disabled.
10	ECU page	Disable/ Enable	Set whether the ECU page is displayed.
11	Date/Time	2000/01/01- 2099/12/31	Internal calendar, please calibrate regularly.
12	Current time	00:00-23:59	

B)Automatic maintenance

No	Parameter	Range (defaults)	Notes
1	Working plan format	Disable Every month Every week	This mode must be under auto mode. Working plan is disabled once setting as disable. The working plan will be executed according the chosen date when setting as every month. The working plan will be executed according the chosen date when setting as every week.
2	Maintenance date per month	From 1 st to 31 st Default: the first day	The date chosen for every month.
3	Maintenance date per week	Monday to Sunday Default: Sunday	The date chosen for every week.
4	Reserved		
5	Maintenance start time	00:00-23:59 (00:00)	Maintenance start time setting.
6	Maintenance running time	1-120m (5<i>min</i>)	Maintenance running time setting.

C)Maintenance Plan

NO	Parameter	Range (default)	Notes
1	Countdown to oil change	0-5000h (5000h)	When it is set as 5000, then this function is
2	Air filter H	0-5000h (5000h)	disabled.
3	Fuel filter H	0-5000h (5000h)	
4	Oil filter replacement date	2000/01/01- 2099/12/31	When it is set as 2000/01/01, this function is
5	Air filter D	2000/01/01-2099/12/31	disabled.
6	Fuel filter D	2000/01/01-2099/12/31	
7	engine oil filter expires action	Warn Delayed alarm stop Alarm and stop	engine action after the oil expires.
8	Air filter expiration	<i>Warn</i> Delayed alarm stop	engine action after the air filter expires.



	action	Alarm and stop	
	Fuel filter	Warn	engine action after the fuel filter expires.
9	expiration	Delayed alarm stop	
	action	Alarm and stop	
10	Maintenance due delay time	0-500.0h (1.0h)	If after the maintenance expires, after the engine starts successfully, after the set time, the maintenance expired shutdown alarm will be reported.
11	Maintenance expiry reset password	0-65535 <i>(06869)</i>	When the maintenance countdown time arrives, enter the password to reset the maintenance countdown time, this password cannot be the same as the parameter setting password.

D)Limited time function

NO	Parameter	Range (default)	Notes
1	Factory limited time	0-5000h (5000h)	Set the accumulated time allowed by the manufacturer to run the engine. After the timer expires, the engine will not run. Entering a temporary password can ensure that the engine will start at one time. When set to 5000, this function is disabled.
2	Temporary password one	0-65535 (11111)	After the manufacturer's time limit is set, the temporary password 1 will become invalid after one use;
3	Temporary password two	0-65535 (22222)	After the manufacturer's time limit is set, the temporary password 2 will become invalid after one use;
4	Temporary password three	0-65535 (33333)	After the manufacturer's time limit is set, the temporary password 3 will become invalid after one use;
5	Factory release password within a limited time	0-65535 (44444)	After the manufacturer's time limit is set, enter this password to permanently unlock the password;

Fault finding

Symptoms	Possible Solutions
Controller no response with power	Check DC voltage.
	Check DC fuse.
	Check if the terminal 1 and 2 is with battery voltage.
Units shutdown	Check the water/cylinder temperature is too high or not.
	Check DC fuse.
Emergency Stop	Check the emergency stop button.
	Check that the voltage of the controller's 3 feet to the ground
	should be the battery voltage.
	Check the controller connection.
Low oil pressure	Check oil pressure sensor and its wiring.
alarm	Check the oil pressure sensor type and controller settings must



	be consistent.
	Check whether the low oil pressure sensor is normal.
High temperature alarm	Check temperature sensor and its wiring.
	Check the temperature sensor type and controller settings must
	be consistent.
	Check whether the temperature sensor is normal.
Shutdown Alarm in running	Check related switch and its connections according to the
	information on LCD.
	Check programmable inputs.
Fail to start	Check the engine fuel circuit and its connecting wires;
	Check whether the starting battery voltage is normal;
	Check the speed sensor and its connecting wire;
Starter motor does	Check the wiring to the starter.
not respond	Check start battery.
USB communication is abnormal	Check the USB connection.
	Check whether the USB port of the computer is normal.
	Check whether the USB driver is installed.
RS485 cannot communicate normally	Check the connection.
	Check if the communication ID number setting is correct.
	Check if the A and B lines of RS485 are reversed.
	Check if the RS485 communication line driver is installed or not.
	Check if the communication port of the PC is damaged.
	Add a 120 Ω resistor between the AB of the controller RS485.
ECU warning or stop	Get information from LCD of alarm page;
	If there is detailed alarm, check engine according to description.
	If not, please refer to engine manual according to SPN alarm
	code.