

EC40CR ENGINE CONTROLLER USER MANUAL



Software Version

No.	Version	Date	Note
1	V1.0	2024-07-25	Original release.
2	V1.1	2025-01-16	Upgrades: Duty Plan, DPF functions; Stop Delay On Manual, CAN protocol and other functions;
3	V1.2	2025-07-04	Add CAN protocol, warning/alarm codes, and other functions;



Chongqing Mebay Technology Co.,Ltd

Add: No6-2,Building 4, Gangan Rd, Jiangbei District, Chongqing.

Tel: +86-23-6869 3061

Fax: +86-23-6765 8207

Web: <http://www.mebay.cn>

<http://www.cqmb.cn>

E_mail: sales@mebay.cn

Controller models to which this manual applies:

EC40CR

Symbol Description

Symbol	Description
 Note	Remind operators to operate correctly, otherwise it may cause the equipment not to work correctly.
 Be care	It is indicated that potential hazards can damage equipment without proper precautions.
 Warning	It is indicated if appropriate preventive measures are not taken, potentially dangerous situations may result in death, serious personal injury or significant property losses.

**Warning**

- 1.The installation of this equipment must be carried out by professionals.
- 2.When installing and operating the controller, please read the entire instruction manual first.
- 3.Any maintenance and commissioning of the equipment must be familiar with all the equipment.
- 4.Safety standards and precautions in advance, otherwise it may cause personal injury or damage to related equipment.
- 5.After the installation of the controller is completed, please verify that all protection functions are valid.

**Be Care**

- 1.Please keep the good connection of the power supply of the controller. Do not share the connection lines of the positive and negative electrodes of the battery with the floating charger.
- 2.During the operation of the engine, do not disconnect the battery, otherwise it may cause damage to the controller.

Catalogue

Summary	7
Main Features	7
Parameters Display	8
Protection	8
Parameters	8
Overall Dimension and Wiring Diagram	9
Installation instruction	15
Panel and display	16
Key Function Description	16
Setting Menu instructions	23
Warnings and Shutdown Alarms	25
Parameter setting	33
Fault finding	53

Notes:

1. All rights reserved. No part of this duplication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or others) without the written permission of the copyright holder.
2. MEBAY Technology reserves the rights to change the contents of this document without prior notice.

Summary

This series of controllers are mainly used in engine control systems for water pumps, lighthouses, air compressors and engineering machinery types, applicable to stand-alone automatic control monitoring system, with remote start and stop, data measurement, alarm protection functions.

2.8 inch LCD screen display with brand new UI design is adapted in this controller can display related parameters directly. The LCD screen can display various faults at the same time. Once the unit does not run normally, it can effectively achieve protection.

There are Chinese/English interface options, more language can be set according to user's request. All the parameters can be configured through the front face buttons or use programmable interface by RS485 or USB to adjust via PC.

Main Features

- ◆ 32bit high performance single chip microcomputer.
- ◆ 2.8 inch LCD screen, It has 16 display languages including Chinese and English, user's language set if necessary.
- ◆ Indicator and number display through UI surface.
- ◆ Acrylic material is adapted to protect the screen.
- ◆ Silicone panels, waterproof, oil-proof, UV-resistant, good operation feel and long service life.
- ◆ USB Port: parameters can be set even without power through USD port to monitor in real time.
- ◆ With RS485 communication port, can achieve "Three Remote" functions via MODBUS protocol.
- ◆ Standard CAN communication port, built-in J1939 protocol.
- ◆ Various kinds of parameters display.
- ◆ Input/output function, status can be shown directly.
- ◆ More categories of surface setting.
- ◆ Real time clock inside: preset time operate and auto maintenance is available. Engine working plan can be set as per week or month.
- ◆ Protection countdown function, which can set the maintenance time or date.
- ◆ Equipped with black box function: capable of storing 100 sets of alarm records, including relevant parameters of the unit when a fault alarm occurs, facilitating the search for the cause of the fault;
- ◆ Equipped with event recording function: can save 5000 system operation logs;
- ◆ Equipped with operation record storage function: can save 5000 engine operation records for easy understanding of engine operation status;
- ◆ Totally 7 relay's output, among which 5 relay output can be self-configurable, each relay can be set as max 80 functions.
- ◆ With 6 switches input, up to 50 functions optional.
- ◆ 6 sensor simulation input connectors, 3 input types is configurable and various kinds of units can be set.
- ◆ Battery charging control function, which can protect the battery according to battery voltage status.
- ◆ Sensor can be self-defined by front face button or PC software.
- ◆ Various of crank conditions (RPM, External input , Oil Pressure,) can be chosen.
- ◆ Control Protection: Auto Start/Stop of unit, perfect failure display and protection.
- ◆ Standard water-proof rubber gasket. The waterproof can reach IP65.
- ◆ Module design: All the connections are adapted with European connectors so that installation, connection, repair and replacement can be more easily.

Parameters Display

- ◆ Engine RPM
- ◆ Engine oil pressure
- ◆ Engine water temperature
- ◆ AUX.sensor parameters
- ◆ Engine battery voltage
- ◆ Charging voltage
- ◆ Cumulative power-on time
- ◆ Total Crank times
- ◆ Current running time
- ◆ Total running time
- ◆ Maintenance notice
- ◆ 6 switches input status display
- ◆ Output status display of 7 relays

Protection

- ◆ Over speed
- ◆ Under speed
- ◆ RPM Lost
- ◆ Low oil pressure
- ◆ High Engine water temperature
- ◆ Low fuel level
- ◆ Fail To Start
- ◆ Fail To Stop
- ◆ Emergency pull over
- ◆ Sensor Open
- ◆ ECU alarm failure
- ◆ ECU communication Failure
- ◆ Low water level alarm
- ◆ Failed to charge
- ◆ Over battery voltage
- ◆ Under battery voltage
- ◆ External real-time alarm
- ◆ Maintenance expire
- ◆ All warnings
- ◆ Alarm shutdown


Parameters


Options	Parameters
Working voltage	DC 8V----36V Continuous
Power consumption	Working: 24V MAX 1W (Standby:24V MAX 5W)
Rotate speed sensor Frequency	50-10000 Hz(AC1~70V)
MAX Accumulating Time	99999.9Hours (Min Store time:0.01H)
Crank Start Relay Output	Max 5Amp/250VAC Non-contact normally Open output
AUX. OUTPUT 1-5	Max 5Amp/250VAC Non-contact normally Open output
AUX. OUTPUT 6	Max 3AMP/250V Non-contact normally Open&Closed output
Sensor INPUT	6 configurable sensor inputs
Excitation output	DC+VE supply voltage

AUX.INPUT 1-6	Available if connecting with Battery -
Working condition	-25-70℃
Storage condition	-30-80℃
Protection Level	IP65: when waterproof rubber gasket is added between controller and its panel
Insulation strength	Apply AC 2.2kV voltage between high voltage terminal and low voltage terminal; The leakage current is not more than 3mA within 1min.
Overall dimension	142mm*105mm*45mm
Panel cutout	116mm*90mm
Weight	0.5Kg


Overall Dimension and Wiring Diagram

◆ Overall Dimension:






◆ Descriptions of terminal connection



No.	Function	Description	Cable cross sectional area
1	Battery Negative Input B-	Controller power supply input B-.	1.5mm ²
2	Battery Negative Input B+	Controller power supply input B+.	1.5mm ²
3	COM 1 Relay Common Port	Relay output common port of No.4 and No.5.	1.5mm ²
4	Crank Output	Non-contact normally opened output, Max 5Amp.	1.5mm ²
5	Aux. Output 1	Non-contact normally opened output, Max 5Amp.	1.5mm ²
6	COM 2 Relay Common Port	Relay output common port of No.7, No.8 and No.9.	1.5mm ²
7	Aux. Output 2	Active output, Max 5Amp/250V.	1.0mm ²
8	Aux. Output 3	Active output, Max 5Amp/250V.	1.0mm ²

9	Aux. Output 4		Active output, Max 5Amp/250V.	1.0mm ²
10	Aux. Output 5	Normally Open	Non-contact normally opened output, Max 5Amp/250V.	1.0mm ²
11		COM		1.0mm ²
12	Aux. Output 6	Normally Open	Non-contact normally opened/closed output, Max 3Amp/250V.	1.0mm ²
13		Normally Close		1.0mm ²
14		COM		1.0mm ²
15	CAN_H		ECU communication interface : 120Ω impedance shielding wire is recommended with one end grounded.	0.5mm ²
16	CAN_L			0.5mm ²
17	RS485 A		RS485 communication interface : 120Ω impedance shielding wire is recommended with one end grounded.	0.5mm ²
18	RS485 B			0.5mm ²
19	Aux. Input 1		The grounding is valid according to the function selection switch input.	1.0mm ²
20	Aux. Input 2			1.0mm ²
21	Aux. Input 3			1.0mm ²
22	Aux. Input 4			1.0mm ²
23	Aux. Input 5			1.0mm ²
24	Aux. Input 6			1.0mm ²
25	Charger D+ output		Active output, Connected with D+(W/L) terminal of charger.	1.0mm ²
26	Aux. Input COM		Internally connected to B-	1.0mm ²
27	Charger W/L		Connect with W terminal of charging engine.	1.0mm ²
28	Speed sensor MP2 (connect with B-)		Use a shielded wire to connect the speed sensor.	1.0mm ²
29	Speed sensor MP1			1.0mm ²
30	AUX.Sensor 1-Engine temperature sensor		Sensor inputs are configurable. (only resistive type can be configured)	1.0mm ²
31	AUX.Sensor 2_Oil pressure sensor		Sensor compatible with voltage ,current and resistance.	1.0mm ²
32	AUX.Sensor 3		Sensor inputs are configurable. (only resistive type can be configured)	1.0mm ²
33	AUX.Sensor 4		Sensor inputs are configurable. (only resistive type can be configured)	1.0mm ²
34	AUX.Sensor 5		Sensor compatible with voltage ,current and resistance.	1.0mm ²
35	AUX.Sensor 6		Sensor compatible with voltage ,current and resistance.	1.0mm ²
36	+5V Output		Connect the power supply of the oil pressure sensor with the output voltage signal, with a maximum of 50mA.	1.0mm ²
37	Sensor common GND		Connect the battery negative or outer.	1.0mm ²

◆ EC40CR Typical Wiring Diagram



NOTE: The Charger negative needs to be separately connected to the case or the negative terminal of the battery.



NOTE: To ensure reliable operation of the module and the measuring accuracy, Try not to share the power cord with other devices.

◆ D-Driven pump start/stop operation and wiring diagram.

- 1) Set input function: D-driven pump started, press. to suction pump.
- 2) Set output function: D-driven pump start, D-driven pump stop.
- 3) Suction pump type: D-driven.
- 4) D-driven pump start:


① After auto/manual mode start is active, preheat relay outputs (if configured), and LCD displays "Preheat delay XX". After preheat delay finished, starting relay outputs (needs to be configured). If crank success input (needs to be configured) is invalid during "D-driven pump cranking Time", starting relay stops output and it will go

to “suction pump crank rest” then waiting for next crank. If the pump doesn’t crank successfully in setting cranking times, controller will issue crank failure shutdown and in the meanwhile it will show “suction pump crank failure” in LCD display.

② In any time of cranking, if D-driven pump crank success, it will enter to “waiting press.to” delay. When delay is expired, “press. to suction pump” (needs to be configured) is invalid and controller will raise alarm and shutdown, and meanwhile “suction pump fault” will be displayed on LCD.

③ During the time of “waiting pressure to”, fuel relay output set “prestart fuel time” (default 1s) after “press. to suction pump” (needs to be configured) is valid, and then starting relay outputs. The rest starting processes are same with auto start procedure.

5) D-driven pump stop: After “safety on delay”, “D-driven pump stop” outputs (needs to be configured), and it stops to output after “Energize to stop time”.



◆ E-Driven pump start/stop operation and wiring diagram.


- 1) Set input function: Press. to Suction Pump.
- 2) Set output function: E-driven Pump Start.
- 3) Suction pump type: E-driven.
- 4) driven Pump Start: After suction pump type is set as E-driven pump and “Safety On Delay” is over, the starting relay outputs (needs to be configured).
- 5) driven Pump Stop:

① While engine is between start idle and high-speed cooling time, if input is “Press. to Suction Pump” (needs to be configured) or outlet pressure is larger than the value of E-driven stop outlet pressure value, the starting relay stops output.

② While engine is in “Energize to Stop Delay”, the starting relay stops output.




NOTE: The mentioned outlet pressure of E-driven pump needs to be set in outlet pressure correlation setting, then relate to corresponding programmable sensor.



Installation instruction

- ◆ The controller is fixed by two special fixing members and screws, and the screws of the metal fasteners cannot be too tight.
- ◆ Panel Cutout: W116mm*H90mm.



Note: If the controller is installed directly in the engine shell or other fluctuated equipment, the rubber pad must be installed.

◆ Battery Voltage Input

EC40CR controller is suitable for 8-36V DC battery voltage. Battery negative must be reliably connected to the enclosure of the engine. The controller power supply B+ and B- must be connected to battery positive and negative, and the wire size must not be less than 1.5mm².



NOTE:

In case of floating charger connect charger output to battery positive and negative directly, then, connect battery positive and negative poles to controller positive and negative power supply.


◆ Output and relay expansion



Note: All outputs of the controller are relay contacts. The maximum current capacity is described in the "Parameters" in this manual. Please use it in the relay current capacity. If an extended relay is needed, add a continuous current diode (when the extended relay coil is DC) or a resistance-capacitance loop (when the extended relay coil is AC) to both ends of the coil to prevent interference with the controller or other equipment.



If withstanding voltage test is conducted after the controller has already been installed onto the control panel, please unplug all controller terminal connections in order to prevent high voltage from damaging it.

Panel and display

Key Function Description

KEYS	NAME	Main Function
	Stop Revert	<ul style="list-style-type: none"> ◆ In manual/automatic mode, stop the engine when pressed.; ◆ In stopping process, press this key again to stop the engine quickly. ◆ In setup mode, cancel the modification and return to the upper menu; ◆ In setting mode parameter browsing mode, press it to exit the setting interface and save the data. ◆ In the standby state of stopping gear and without any alarm, press this key for 3 seconds to view the alarm record. ◆ In the alarm state, you can reset any alarm shutdown.
	Start	<ul style="list-style-type: none"> ◆ In manual mode, press this key to start the engine; the ◆ In stop gear, pressing this key oil valve and ECU power will output. (Valid when engine type is configured for CAN protocol). ◆ If the idle delay is pressed after a successful unit start, the idle run time is skipped.
	Auto	<ul style="list-style-type: none"> ◆ Pressing this key will set the module into auto mode.
	Manual	<ul style="list-style-type: none"> ◆ Pressing this key will set the module into manual mode.
	Speed	<ul style="list-style-type: none"> ◆ If the configuration speed control function is on, press this key to enter the speed control interface.
	Up	<ul style="list-style-type: none"> ◆ In setup mode, it will be possible to flip up to move the cursor or increase the number where the cursor is; ◆ In the history fault screen, press and move the cursor

		upwards; ◆ In the display mode, turn the page forward. ◆ In the speed control interface, it will be possible to increase the speed.
	Down	◆ In setup mode, it will be possible to move the cursor down or decrease the number where the cursor is; ◆ In the history fault screen, press and move the cursor downwards; ◆ In the display mode, turn the page backward. ◆ In the speed control interface it will be possible to reduce the speed;.
	OK UI Change	◆ Confirm the change under edition mode. ◆ Shift right under edition mode. ◆ Page exited under records checking mode. ◆ In display mode, press to return to the display home page; ◆ In standby state, press for 3 seconds to enter the parameter setting mode.
	LED Test	◆ Test if all LED lights are OK, pressing this key to test if all lighted, all off when loosen it.
	Setting mode	◆ Pressing OK and STOP simultaneously to come into setting mode

◆ Notices in Starting Process



Note 1: During the Cranking time, the controller automatically detects the speed signal, oil pressure value or the charging voltage (according to the parameter setting) to reach the judgment condition of successful start, then the judgment is that the start is successful and the motor relay is closed.



Note 2: Within the safety delay, only respond to emergency stop, immediate stop, over speed, ECU communication Failure, other alarms are not responded to.



Note 3: No response to alarm and warning of under speed, low frequency, under voltage, over current, over power, non-balance of current, external instant unloading shutdown, during start idle time.



Note 4: After entering the rated operation, the "rated operation" indicator light is on.



Note 5: In the process of shutdown, if the remote starting signal is restored to be valid within the "Cooling time", the rated operation will be entered again.



Note 6: If the stop key is pressed again during idle time, the idle time will be canceled and the stop operation will be executed directly.

◆ sensor association settings



Fuel level sensor correlation: if need to use fuel level function, one of flexible sensor 1~6 needs to be configured as fuel level sensor, meanwhile, curve type needs to correspond to sensor types. Then set the correlated sensor and select the corresponding flexible sensor. At this time, the flexible sensor is the fuel level sensor, which can realize fuel pump control and tank volume display.



Outlet pressure correlation: if need to calculate flow and head via water pressure gauge, one of flexible sensor 1~6 needs to be configured as outlet pressure sensor, meanwhile, curve type needs to correspond to sensor types. Then set the correlated sensor and select the corresponding flexible sensor. At this time, flow and head can be calculated via outlet pressure gauge.

Outlet pressure correlation also needs to be configured if E-driven suction pump needs to judge whether to stop the output according to the outlet pressure.



Temperature sensor correlation: If you need to control (heating, cooling, choke) by temperature, one of flexible sensor 1~6 needs to be configured as temperature sensor, meanwhile, curve type needs to correspond to sensor types. Then set the correlated sensor and select the corresponding flexible sensor then you can control (heating, cooling, damper) by temperature.

◆ Idle mode:

- 1) Input port is configured as : Idle Mode.
- 2) If engine is normally running and idle mode input is active, controller will enter into idle mode and engine will start idle running. Then idle control relay will be energized and drop speed relay will output.
- 3) If engine is in standby status and idle mode input is active, engine will be started in manual mode or auto mode. When “Safety On Delay” is over, engine will enter into “Start Idle Delay” (if configured), and after this delay expired, engine will start idle running. Then idle control relay energized and drop speed relay will output.
- 4) While in idle mode and engine is idle running, if idle mode input is inactive, controller will exit idle mode, and engine will enter into normal running. Both Idle control relay and drop speed relay stop outputing.
- 5) While in idle mode and engine is idle running, press to  active stop operation, and then engine enters from “Idle Running” to “Stop Idle Delay” . The remaining stop process is the same as auto stop procedure.

◆ Idle/High speed mode:

- 1) Input port is configured as : Idle/High speed.
- 2) If engine is normally running and idle/high speed input is active, engine will start idle running. Then idle control relay will be energized and drop speed relay will output. If speed regulation is configured as relay adjust speed or CAN adjust speed, press raise speed key, idle control relay and drop speed relay will stop output, and speed can be adjusted during idle running.

3) If engine is in standby status and idle/high speed input is active, engine will be started in manual mode or auto mode. When "Safety On Delay" is over, engine will enter into "Start Idle Delay" (if configured), and after this delay expired, engine will start idle running. Then idle control relay energized and drop speed relay will output. If speed regulation is configured as relay adjust speed or CAN adjust speed, press raise speed key, idle control relay and drop seed relay will stop output, and speed can be adjusted during idle running.

4) If engine is in idle running, when idle/high speed input is inactive, it will exit idle running and enter into high-speed warming up status and raise speed relay outputs. When "High-speed Warming Up Delay" expired, raise speed relay stops output, and engine enters into normal running. After speed regulation type has been configured, speed can be adjusted in normal running status.

5) While engine is in idle running status, press to  active stop operation, and then engine enters from "Idle Running" to "Stop Idle Delay" (if configured). The remaining stop process is the same as auto stop procedure.

◆ Engine speed control

 **Note:** 1) The "Speed Setting" menu responds to the overspeed alarm: the alarm value is: (Maximum speed value * overspeed alarm percentage) in the <[Adjust Speed Setting](#)>.

2) Exit the "Speed Setting" menu and the overspeed alarm value: Target speed * overspeed alarm percentage.

1) In the "Speed Setting" menu, if you set the speed setting type: "0: Disable", the engine speed setting function will be disabled, and you cannot enter the speed

setting interface by pressing the  key;

2) In the "Speed Setting" menu, if you set the type of speed control: "1:CAN Speed

Control - Key", then press  key to enter the speed control interface, then press

 key to increase speed, press  key to decrease speed, and press  key to exit the speed control interface and stop speed control. As shown in the figure below:

Engine speed control	
Target speed:1500RPM	
Current speed:1499RPM	
Increase: 	decrease: 
Speed control: increasing speed ...	

 **Note:** When the CAN speed control type is set to "1:CAN speed control - key", the engine can be speed controlled at idle or rated operation!

3) In the menu of "Speed Setting", if you set the type of speed control: "2:CAN Speed Control - AUX input", you must set the two switching quantity inputs as "Speed up " and "Speed down", and connect the external self-reset switch; press the key to enter the speed control interface, at this time, the engine speeds up when the speed up switch is effective, and the engine speeds down when the speed down

switch is effective. **"Speed up"** and connect the external self-reset switch; press  key to enter the speed control interface, at this time, the engine speeds up when the speed up switch is effective, and the engine speeds down when the speed down switch is effective; press  key again to exit the speed control interface and stop speed control.

Engine speed control	
Target speed:1500RPM	
Current speed:1499RPM	
Increase: 	decrease: 
Speed control: increasing speed ...	

4) In the "Speed Setting" menu, if you set the type of speed control: "3:CAN speed control-1 or 2", the speed control function of Article 2 and Article 3 above is effective, In the speed control interface, the engine speed can be controlled by the module keys or the external self-reset switch of the AUX input. As shown in the figure below:

Engine speed control	
Target speed:1500RPM	
Current speed:1499RPM	
Increase:  	decrease:  
Speed control: increasing speed ...	

 Note: When the CAN speed control type is set to "3:CAN speed control-1 or 2", the engine can be speed controlled at idle or rated operation!

5) In the "Speed Setting" menu, if you set the speed control type: "4:CAN Speed Control - Potentiometer", you must configure the configurable sensor input as "1: Speed Control Potentiometer", such as Multiple configurable sensor channels are configured as "1: speed potentiometer", then the smallest channel serial number shall prevail; the minimum variable resistance value of external potentiometer is 0-100Ω,

and the maximum value is 0-5000Ω; press  to enter the speed control interface, and at this time, the controller controls the engine speed according to the resistance value of the potentiometer, and it is "idle speed" when the resistance value is 0. At this time, the controller controls the engine speed according to the resistance value of the potentiometer, when the resistance value is 0, it will be "idle speed", when the resistance value is maximum, it will be "maximum speed value" for the speed control; when the resistance value of the potentiometer is increased, the engine speed increases, and when the resistance value is decreased, the engine speed decreases,

and the controller will exit the speed control interface by pressing the  key to stop the speed control again.

Please note when setting the CAN speed control type to "4: CAN speed control - potentiometer":

 (1) The engine is idling after starting, the speed can only be controlled by potentiometer, the external idle/run switch is invalid!

 (2) After the engine is started, when entering the speed control interface for the first time, the resistance value of the potentiometer must be reset to less than 10Ω before the engine speed control can be carried out!

Engine speed control
Target speed:1500RPM
Current speed:1499RPM
Potentiometer resistance:1000Ω
Speed control: increasing speed ...

6) State description of the speed regulation process:

- (1) In descending speed: the controller is performing descending control of the engine;
- (2) Speed up in progress: the controller is performing speed up control on the engine;
- (3) Speed adjustment complete: the controller is completing speed up or speed down control of the engine;
- (4) Please reset the potentiometer: after the engine starts, the resistance value of the speed adjustment potentiometer is greater than 10Ω, please rotate it to the minimum position of the potentiometer;
- (5) Wait for speed regulation: wait for the operator to carry out speed regulation operation.

◆ Emergency start mode:


In manual mode, pressing the  button and the  button at the same time can force the engine to start. At this time, the controller will no longer automatically judge the successful start condition, and the operator will judge the separation of the starter by himself. The operator observes that the unit has started successfully. After releasing the  button, the starter motor will be disconnected immediately, and the controller will enter the "safety protection delay" state.

◆ Manual Start Mode

press  and make sure it is in the stop position before starting.

Press  and the test file indicator is on. At this time, it is detected whether the connection of each sensor is normal. If the sensor is open, the sensor opens an alarm. If it is normal, the unit start process is executed in the following sequence after pressing the . automatically switch to engine provide the power when the unit is running normally. Press  The controller performs the parking process at the following timing:


Manual start and stop process:



◆ Automatic starting mode:

Press 'Stop key'  to ensure that the unit is in stop gear before starting. Press 'auto key' , the indicator light of auto gear is on, at this time, it will detect whether each sensor is connected normally, if the sensor is open circuit, it will report sensor open circuit alarm, if it is normal, it will wait for the remote start signal to be valid, and then the unit will execute the starting process according to the following time sequence. When the unit enters into normal rated operation, the controller detects that the remote start signal is invalid, and the remote stop input signal is valid, then it will execute the 'loop time delay' and the subsequent shutdown process.

Auto start and stop process:



◆ Stop Delay On Manual Mode

- 1、 If you enable this function, after entering the rated operation state, the status bar will show “Rated Running - Stop Delayed : xxx ”minutes countdown.
- 2、 After the delay time, the engine stops, the gear does not change, it is still “Manual”, but the status bar of the screen displays “Delayed Stop Completed”, The customer presses any key and then display “Shutdown mode” normally.
- 3、 **Stop Delay On Manual:** the delay is set to 65000 disabled, other values are enable.

◆ Commissioning and precautions

- 1) Ensure all the connections are correct and wires diameter is suitable;
- 2) Ensure that the controller DC power has fuse, controller’s positive and negative connected to start battery are correct;
- 3) Disconnect the oil valve line and start the engine, the engine group will start to start, after the set number of starts, the controller will send a start failure signal; press the stop button to reset the controller.

- 4) Turn on the oil valve line and check whether the engine data is normal (speed, water temperature, oil temperature, oil pressure); if everything is normal, the unit will run at idle speed (if it is set to idle speed) to normal operation; if there is any abnormality, Stop the engine unit and check the wiring of each part referring to this manual;
- 5) Manual shutdown to confirm normal operation.

Setting Menu instructions

The steps to enter the **Menu** setting are as follows:

Press the key  for more than 3 seconds. Or press the stop key  without releasing, press the  key again, and then release all the keys to enter the setting menu page; The menu contents are as follows:

◆ **Override Control:**

Enter this menu to set whether the override mode is Disable or Enable, override mode is valid: All shutdown alarm quantities are disabled except emergency shutdown and overspeed.

◆ **Set Parameters: please refer to "Parameter".**

◆ **Language/语言: please refer to "Language".**

◆ **Information:** You can view the status information of the controller such as product model, version, and release time.

◆ **Alarm logs**

EC40CR controller can save 100 group of alarm records which contains the alarm record data includes detailed data such as alarm time, prompt status information, etc. How to check the alarm records:

1. Enter alarm record page: Under stop mode, press this  key for 3 seconds come into alarm records page; Enter the setting mode: Select the alarm record and press  key to alarm records page;
2. Press  to turn upper digit and press  to turn lower digit in order to choose the record you need. Press  to confirm the record and come into history records checking page.
3. Press  to turn lower records under records checking page. Press  to turn upper records and press  to revert back to alarm history records page.
4. Exit from records page: In the history records page and checking page, press  to exit;

◆ **Reset Maintenance**

The controllers are equipped with a quick reset maintenance countdown function, which is operated as follows:

- 1) Press the key  for more than 3 seconds to enter the setting menu interface.

2) In the setting menu interface, press  key to move down, select "Maintenance Countdown Reset", and input "Maintenance Countdown Reset Password".

3) In the pop-up dialogue box, select "Yes", the controller will reset the maintenance countdown to the set value.

4) After the maintenance countdown is reset successfully, press the STOP key to exit the setting interface.



Note: The maintenance countdown password cannot be set as the same as the parameter setting password!

◆ **System log**

EC40CR controller can save 5000 system logs, including power-on time, date, cumulative time, starting mode (manual, automatic, unknown.), running time, stopping mode (manual, automatic, alarm stop, unknown), and writing running time and mode at intervals.

The steps to view the system log are as follows:

1) Press the key  for more than 3 seconds. Or press the stop key  without releasing, press the OK key  again, and then release all the keys to enter the setting menu page;

2) In the setting menu page, select "System log" and press the OK key  once to enter the System logs page;

3) In the System Operational Record page, press the up key  and down key  to browse the operation log, and the latest operation is recorded in the front; press the STOP key  to exit the System Operational Records page.

◆ **DPF Regeneration**

No	Parameters	Range(defaults)
01	DPF Regeneration Requested	0-Disable; 1-Enable
02	DPF Regeneration Inhibit	0-Disable; 1-Enable
03	DPF Regeneration Bus Control	0-Disable; 1-Enable
04	Urea Level Low Warning Value	0.0-100.0% (10.0%)



Available for ECU which require the engine speed to drop during a manual regeneration cycle. During this time, the generator is not available to supply power and the under speed and under frequency alarms are not active.



There are two ways to enable and disable the regeneration function:
 1: Controller parameter setting page to enable or disable, after re-power on **DPF Regeneration Inhibit, DPF Regeneration** will be reset to disable.

2: **AUX.Input control:**

DPF Regeneration Inhibit: This input is used to override the ECU function and

prevent the regeneration of the diesel particulate filter.

DPF Regeneration: This input is used to override the ECU function and activate the regeneration of the diesel particulate filter.

Regeneration is divided into hardware regeneration control and bus regeneration control; hardware regeneration is controlled by module relay Output;

DPF Regeneration Inhibit Request: when the output is active , the diesel particulate filter regeneration inhibit.

DPF Regeneration Requested: Outputs an indication when diesel particulate filter regeneration is requested;

DPF Forced Regeneration: When the output is valid: forced regeneration of the diesel particulate filter.

DPF Regeneration In Progress: Output indication when diesel particulate filter regeneration is in progress.

Bus regeneration is realized by sending CAN commands; when the controller regeneration function is turned on, CAN commands are automatically sent to realize DPF forced regeneration.

Warnings and Shutdown Alarms

◆ Warnings



Notes: Warning is a non-serious failure state, which will not harm the gensets system for the time being. It only reminds operators to pay attention to the situation that does not meet the requirements and solve it in time to ensure the continuous operation of the system. When the warning occurs, the gensets does not stop. Once the fault is removed, the warning is automatically canceled.



Note: When a warning fault occurs, the warning indicator "**WARNING**" is always on, and the current fault interface displays the warning description, Generators will not stop.

Code	Display name	Description
A0	Over speed	When the controller detects that the engine speed is higher than " Over speed warning ", after the warning delay, it will report the " Over speed " warning.
A1	Under speed	When the controller detects that the engine speed is lower than " Under speed warning ", after the warning delay, it will report the " Under speed " warning.
A7	Oil pressure low	When the controller " Oil Pressure Sensor Alarm Action " is set to " Warning ", detected sensor less than the "Warning Threshold", after the warning delay, it will report the " Oil pressure low " warning.
A8	Temperature high	When the controller " Temperature Sensor Alarm Action " is set to " Warning ", detected sensor higher than the "Warning Threshold", after the warning delay, it will report the " Temperature high " warning.
A11	Fuel level sensor	When the controller " Fuel level Sensor Alarm

	low	Action" is set to "Warning", detected sensor less than the "Warning Threshold", after the warning delay, it will report the "Fuel level sensor low" warning.
A12	Low fuel level switch	When the controller detects that the AUX. Input "Low fuel level warning input" switch is active, after the warning delay, it will report the "Low fuel level switch" warning.
A13	Under battery voltage	When the controller detects that the battery voltage is lower than the "Under battery voltage warning" , after the warning delay, it will report the "Under battery voltage" warning.
A19	High WT switch	When the controller detects that the AUX. Input "High water temperature warning" switch is active, after the warning delay, it will report the "High WT switch" .
A26	Instant warning switch	When the controller detects that the AUX. Input "External instant warning input" switch is active, after the warning delay, it will report the "Instant warning switch" .
A28	RPM Signal lost	When the controller parameter "Action if RPM lost" is set to "warning" , the detected speed value is 0, after the warning delay, it will report the "RPM Signal lost" warning.
A29	Oil Pressure Sensor disconnect	When the controller "Action if oil pressure sensor disconnected" is set to "warning" , When the oil pressure sensor is detected to be disconnected, it will report the "Oil Pressure Sensor disconnect"
A30	Temperature sensor disconnect	When the controller "Action if temperature sensor disconnected" is set to "warning" , When the water temperature sensor is detected to be disconnected, it will report the "Temperature sensor disconnect"
A34	Fuel level sensor disconnect	When the controller "Action if Fuel level sensor disconnected" is set to "warning" , When the fuel level sensor is detected to be disconnected, it will report the "Fuel level sensor disconnect"
A44	ECU Warn	When the controller detects a warning message from the ECU, after the warning delay, an ECU warning is reported (The corresponding ECU warning code displayed).
A45	ECU Comms. fail	When the controller parameter "ECU failure" Action is set to "warning" , and no message is received from the ECU within a fixed period of time, it will report "ECU Comms.fail" warning.
A46	Low water level switch	When the controller detects that the AUX. Input "Low water level warning" switch is active, after the warning delay, it will report the "Low water level switch" warning.
A47	Over battery voltage	When the controller detects that the battery voltage is over than the "Over battery voltage warning" , after the warning delay, it will report the "Over battery voltage" warning.

A48	Charger fault	When the controller detects that the voltage difference between D+ and B+ is greater than the " Charger warning voltage difference ", after the warning delay, it will report " charger fault " warning.
A49	Battery charger fault	When the controller detects that the AUX. Input " Charging failure warning " switch is active, after the warning delay, it will report " Battery charger fault " warning.
A50	Low OP switch	When the controller detects that the AUX. Input " Low oil pressure warning " switch is active, after the warning delay, it will report the " Low OP switch " warning.
A 68	Fuel Filling System Fault	When the controller " Fuel Pump Output " is active, if no increase in fuel level is detected during the "Fuel Pump Filling detection time ", it will report the " Fuel filling system fault " warning.
A 70	AUX.Sensor 1 low	When the controller parameter " Sensor alarm Action " is set to " Warning ", and the controller detects that the sensor value is lower than " Warning Threshold ", after the warning delay, it will report the " AUX.Sensor low " warning.
A 71	AUX.Sensor 2 low	
A 72	AUX.Sensor 3 low	
A 73	AUX.Sensor 4 low	
A 74	AUX.Sensor 5 low	
A 75	AUX.Sensor 6 low	
A 76	AUX.Sensor 1 high	When the controller parameter " Sensor alarm Action " is set to " Warning ", and the controller detects that the sensor value is higher than " Warning Threshold ", after the warning delay, it will report the " AUX.Sensor low " warning.
A 77	AUX.Sensor 2 high	
A 78	AUX.Sensor 3 high	
A 79	AUX.Sensor 4 high	
A 80	AUX.Sensor 5 high	
A 81	AUX.Sensor 6 high	
A 82	AUX.Sensor 1 Disconnect	When the controller parameter " Action if sensor disconnected " is set to " warning ", When the sensor is detected to be disconnected, after the warning delay, it will report the " AUX.Sensor Disconnect " warning.
A 83	AUX.Sensor 2 Disconnect	
A 84	AUX.Sensor 3 Disconnect	
A 85	AUX.Sensor 4 Disconnect	
A 86	AUX.Sensor 5 Disconnect	
A 87	AUX.Sensor 6 Disconnect	
A88	AUX.Input 1 fault	When the controller detects that the " AUX. Input " switch is active,after the warning delay, it will report the " AUX.Input " warning.
A89	AUX.Input 2 fault	
A90	AUX.Input 3 fault	
A91	AUX.Input 4 fault	
A92	AUX.Input 5 fault	
A93	AUX.Input 6 fault	
A 98	DPF Regeneration Requested	When the DPF function is on, when the controller receives the corresponding ECU telegram warning information, it reports the corresponding warning.
A 99	DPF Regeneration	

	Inhibit Request	
A100	High Exhaust System Temperature	
A101	DPF Regeneration In Progress	
A102	Low DEF level	
A106	Potentiometer disconnect	When the controller parameter " Action if sensor disconnected " is set to " warning ", When the sensor is detected to be disconnected, after the warning delay, it will report the " AUX.Sensor Disconnect " warning.
A107	Liquid level sensor disconnect	
A108	Pipe Network pressure sensors disconnect	
A109	Inlet pressure sensor disconnect	
A110	Outlet pressure sensor disconnect	
A111	Torque converter oil temperature sensor disconnect	
A112	Water level sensor disconnect	
A113	water pressure sensor disconnect	
A114	Coolant temperature sensor disconnect	
A115	Exhaust gas temperature sensor disconnect	
A116	Exhaust gas pressure sensor disconnect	
A117	Intake pressure sensor disconnect	
A118	Primary pressure sensor disconnect	
A119	Secondary pressure sensor disconnect	
A120	System pressure sensor disconnect	
A121	Flow sensor disconnect	When the controller parameter " Sensor alarm Action " is set to " Warning ", and the controller detects that the sensor value is higher than " Warning Threshold ", after the warning delay, it will report the " AUX.Sensor low " warning.
A122	Potentiometer high	
A123	Oil Pressure Sensor high	
A124	Liquid level sensor high	
A125	Fuel level sensor high	
A126	Pipe Network pressure sensors high	
A127	Inlet pressure sensor high	
A128	Outlet pressure sensor high	
A129	Torque converter oil temperature sensor high	
A130	Water level sensor high	
A131	water pressure sensor high	
A132	Coolant temperature sensor high	
A133	Exhaust gas temperature sensor high	
A134	Exhaust gas pressure sensor high	
A135	Intake pressure sensor high	
A136	Primary pressure sensor high	
A137	Secondary pressure sensor high	
A138	System pressure sensor high	
A139	Flow sensor high	When the controller parameter " Sensor alarm Action " is set to " Warning ", and the controller detects that the sensor value is lower than
A140	Potentiometer low	
A141	Temperature sensor low	
A142	Liquid level sensor low	
A143	Pipe Network pressure sensors low	
A144	Inlet pressure sensor low	
A145	Outlet pressure sensor low	

A146	Torque converter oil temperature sensor low	"Warning Threshold" , after the warning delay, it will report the "AUX.Sensor low" warning.
A147	Water level sensor low	
A148	Water pressure sensor low	
A149	Coolant temperature sensor low	
A150	Exhaust gas temperature sensor low	
A151	Exhaust gas pressure sensor low	
A152	Intake pressure sensor low	
A153	Primary pressure sensor low	
A154	Secondary pressure sensor low	
A155	System pressure sensor low	
A156	Flow sensor low	
A157	Over flow Warn	When the meter detects that the flow rate exceeds the 'over flow Warn threshold' , after the warning delay, it will report the Over flow shutdown warning.
A177	Oil / Filter expired	When the controller parameter "Oil / Filter expiration" is set to "warning" , when the oil / filter to maintenance is detected as "0" or date less than current date, after the warning delay, it will report the "Oil / Filter expired" warning.
A178	Air filter expired	When the controller parameter "Air filter expiration" is set to "warning" , when the Air filter to maintenance is detected as "0" or date less than current date, after the warning delay, it will report the "Air filter expired" warning.
A179	Fuel filter expired	When the controller parameter "Fuel filter expiration" is set to "warning" , when the fuel filter to maintenance is detected as "0" or date less than current date, after the warning delay, it will report the "Fuel filter expired" warning.

◆ Shutdown Alarms



Warning: After the Shutdown Alarm occurs, the system will be locked immediately and the generator set will be stopped. Only after troubleshooting, press



key to clear the alarm, can it be re-operated.



Notes:When the shutdown alarm failure occurs, the **"ALARM"** lights will light up and the generator unit automatically stops.

Code	Display name	Description
E0	Emergency stop	When the controller detects that the AUX. Input "Emergency stop" switch is active, after the alarm delay, , it will report the "Emergency stop " alarm.
E1	Over speed	When the controller detects that the engine speed is higher than "Over speed alarm" , after the alarm delay, it will report the "Over speed " alarm.
E2	Under speed	When the controller detects that the engine speed is under than "Under speed alarm" , after the alarm

		delay, it will report the "Under speed " alarm, after the alarm delay, it will report the "Under speed " alarm.
E8	Oil Pressure Sensor low	When the controller "Oil Pressure Sensor Alarm Action" is set to "Alarm and stop" , detected sensor less than the "Alarm Threshold" , after the alarm delay, it will report the "Oil Pressure Sensor low" alarm.
E9	Low oil pressure switch	When the controller detects that the AUX. Input "Low oil pressure alarm" switch is active, after the alarm delay, it will report the "Low oil pressure switch" alarm.
E10	Oil Pressure Sensor disconnect	When the controller "Action if oil pressure sensor disconnected" is set to "Alarm and stop" , When the oil pressure sensor is detected to be disconnected, it will report the "Oil Pressure Sensor disconnect"
E11	Temperature sensor high	When the controller "Temperature Sensor Alarm Action" is set to "Alarm and stop" , detected sensor less than the "Alarm Threshold" , after the alarm delay, it will report the "Temperature sensor high" alarm.
E12	High WT switch	When the controller detects that the AUX. Input "High coolant temperature alarm" switch is active, after the alarm delay, it will report the "High WT switch" alarm.
E13	Temperature sensor disconnect	When the controller "Action if temperature sensor disconnected" is set to "Alarm and stop" , When the coolant temperature sensor is detected to be disconnected, it will report the "Temperature sensor disconnect" .
E20	Low water level switch	When the controller detects that the AUX. Input "Low coolant level alarm" switch is active, after the alarm delay, it will report the "Low water level switch" alarm.
E21	Fail To Start	If the number of cranks exceeds the predetermined number of cranks, the "Fail To Start" will be reported if the start-up of the generating unit is still unsuccessful.
E22	RPM Signal lost	When the controller parameter "Action if RPM lost" is set to "Alarm and stop" , the detected speed value is 0, after the alarm delay, it will report the "RPM Signal lost" alarm.
E23	Fail To Stop-RPM	When the controller detects that the speed is not "0" after the execution of the shutdown, it will report the "Fail To Stop-RPM" alarm.
E24	Fail To Stop-Oil pres	When the controller detects that the oil pressure switch has not returned after the stop, it will report the "Fail To Stop-Oil pres" alarm.
E26	Fail To Stop-Oil pres	When the controller detects that the Oil Pressure is

		not "0" after the execution of the shutdown, it will report the " Fail To Stop-Oil pres " alarm.
E32	Fuel level sensor disconnect	When the controller " Action if Fuel level sensor disconnected " is set to " Alarm and stop ", When the Fuel level sensor is detected to be disconnected, it will report the " Fuel level sensor disconnect "
E34	Low fuel level switch	When the controller detects that the AUX. Input " Low Fuel level alarm " switch is active, after the alarm delay, it will report the " Low fuel level switch " alarm.
E39	Instant alarm switch	When the controller detects that the AUX. Input " External instant alarm input " switch is active, after the alarm delay, it will report the " Instant alarm switch " alarm.
E49	ECU Alarm	When the controller detects a alarm message from the ECU, after the alarm delay, an ECU alarm is reported (The corresponding ECU alarm code displayed).
E50	ECU Comms. fail	When the controller parameter " ECU failure " Action is set to " Alarm and stop ", and no message is received from the ECU within a fixed period of time, it will report " ECU Comms.fail " alarm.
E51	Louver opening exception	When opening the Louver control , the controller detects that the AUX. Input " Louver status input " switch is inactive, after the alarm delay, it will report the " Louver opening exception " alarm.
E56	Fuel level sensor low	When the controller " Low fuel level Sensor Alarm Action " is set to " Alarm and stop ", detected sensor less than the " Alarm Threshold ", after the alarm delay, it will report the " Fuel level sensor low "alarm.
E81	Host Comms. fail	When the controller working mode is set to " Slave mode ",and no message is received from the Host within a fixed period of time, it will report " Host Comms. fail " alarm.
E83	AUX.Sensor 1 low	When the controller parameter " Sensor alarm Action " is set to " Alarm and stop ", and the controller detects that the sensor value is lower than " Alarm Threshold ", after the alarm delay, it will report the " AUX.Sensor low " alarm.
E84	AUX.Sensor 2 low	
E85	AUX.Sensor 3 low	
E86	AUX.Sensor 4 low	
E87	AUX.Sensor 5 low	
E88	AUX.Sensor 6 low	
E89	AUX.Sensor 1 high	When the controller parameter " Sensor alarm Action " is set to " Alarm and stop ", and the controller detects that the sensor value is higher than " Alarm Threshold ", after the alarm delay, it will report the " AUX.Sensor low " alarm.
E90	AUX.Sensor 2 high	
E91	AUX.Sensor 3 high	
E92	AUX.Sensor 4 high	
E93	AUX.Sensor 5 high	
E94	AUX.Sensor 6 high	
E95	AUX.Sensor 1 Disconnect	When the controller parameter " Action if sensor disconnected " is set to " Alarm and stop ", When the sensor is detected to be disconnected, after the
E96	AUX.Sensor 2	

	Disconnect	alarm delay, it will report the " AUX.Sensor Disconnect " alarm.
E97	AUX.Sensor 3 Disconnect	
E98	AUX.Sensor 4 Disconnect	
E99	AUX.Sensor 5 Disconnect	
E100	AUX.Sensor 6 Disconnect	
E125	Potentiometer disconnect	When the controller parameter " Action if sensor disconnected " is set to " Alarm and stop ", When the sensor is detected to be disconnected, after the alarm delay, it will report the " AUX.Sensor Disconnect " alarm.
E126	Liquid level sensor disconnect	
E127	Pipe Network pressure sensors disconnect	
E128	Inlet pressure sensor disconnect	
E129	Outlet pressure sensor disconnect	
E130	Torque converter oil temperature sensor disconnect	
E131	Water level sensor disconnect	
E132	Water pressure sensor disconnect	
E133	Coolant temperature sensor disconnect	
E134	Exhaust gas temperature sensor disconnect	
E135	Exhaust gas pressure sensor disconnect	
E136	Intake pressure sensor disconnect	
E137	Primary pressure sensor disconnect	
E138	Secondary pressure sensor disconnect	
E139	System pressure sensor disconnect	
E140	Flow sensor disconnect	
E141	Potentiometer high	When the controller parameter " Sensor alarm Action " is set to " Alarm and stop ", and the controller detects that the sensor value is higher than " Alarm Threshold ", after the alarm delay, it will report the " AUX.Sensor low " alarm.
E142	Oil Pressure Sensor high	
E143	Liquid level sensor high	
E144	Fuel level sensor high	
E145	Pipe Network pressure sensors high	
E146	Inlet pressure sensor high	
E147	Outlet pressure sensor high	
E148	Torque converter oil temperature sensor high	
E149	Water level sensor high	
E150	Water pressure sensor high	
E151	Coolant temperature sensor high	
E152	Exhaust gas temperature sensor high	
E153	Exhaust gas pressure sensor high	
E154	Intake pressure sensor high	
E155	Primary pressure sensor high	
E156	Secondary pressure sensor high	
E157	System pressure sensor high	
E158	Flow sensor high	
E159	Potentiometer low	When the controller parameter " Sensor alarm Action " is set to " Alarm and stop ", and the controller detects that the
E160	Temperature sensor low	
E161	Liquid level sensor low	
E162	Pipe Network pressure sensors low	
E163	Inlet pressure sensor low	

E164	Outlet pressure sensor low	sensor value is lower than " Alarm Threshold ", after the alarm delay, it will report the " AUX.Sensor low " alarm.	
E165	Torque converter oil temperature sensor low		
E166	Water level sensor low		
E167	water pressure sensor low		
E168	Coolant temperature sensor low		
E169	Exhaust gas temperature sensor low		
E170	Exhaust gas pressure sensor low		
E171	Intake pressure sensor low		
E172	Primary pressure sensor low		
E173	Secondary pressure sensor low		
E174	System pressure sensor low	When the controller detects that the flow rate exceeds the ' Over flow shutdown threshold ', after the alarm delay, it will report the over flow shutdown alarm.	
E175	Flow sensor low		
E176	Over flow shutdown		
E183	Suction pump Fail To Start		If crank success input (needs to be configured) is invalid during "D-driven pump cranking Time", If the pump doesn't crank successfully in setting cranking times, controller will report the " Suction pump Fail To Start " alarm.
E184	Suction pump fault		If D-driven pump crank success, it will enter to "waiting press.to" delay. When delay is expired, "press. to suction pump" (needs to be configured) is invalid and controller will report the " Suction pump fault " alarm.
E195	Oil / Filter expired		When the controller parameter " Oil / Filter expiration " is set to " Alarm and stop ", when the oil / filter to maintenance is detected as "0" or date less than current date, after the alarm delay, it will report the " Oil / Filter expired " alarm.
E196	Air filter expired		When the controller parameter " Air filter expiration " is set to " Alarm and stop ", when the Air filter to maintenance is detected as "0" or date less than current date, after the alarm delay, it will report the " Air filter expired " alarm.
E197	Fuel filter expired		When the controller parameter " Fuel filter expiration " is set to " Alarm and stop ", when the fuel filter to maintenance is detected as "0" or date less than current date, after the alarm delay, it will report the " Fuel filter expired " alarm.

Parameter setting

◆ Enter the edition page

Please set the parameters according to below steps:

- 1) The setting mode can be active after pressing  and  simultaneously, under the status of standby without any alarm. The default password is "**07623**".

- 2) Press  and add number 1, press  to reduce number 1, press  to turn the digit into right, press  once done. Then system comes into menu after confirmation of password setting. The screen will display error if password is wrong. The correct password should be put after pressing any button.
- 3) Press  to turn the digit into upper position, press  to turn the digit into lower position, press  to get into parameters setting page.
- 4) Press  to shift up the parameters, press  to shift down the parameters, press  to get into parameter changing page.
- 5) Press  to add number 1, press  to reduce number 1, press  to turn the digit into right, press  once done. If the parameters setting is in the valid setting range, then it can be saved, if not, it can not be saved.
- 6) Press  and  to save the parameters and exit from edition page.
- 7) Press  to revert back to last class if in any setting position.

 Revert back to default: put password "97011" when coming into parameters setting, then all the parameters can be set as defaults.

 Note: the data can't be saved if the user didn't press  to confirm the setting.

◆ Parameter list.

0) Language settings

No	Parameter	Range(defaults)	Notes
1	Language	0-English 1-简体中文 2-繁体中文 3-Espanol 4-Русский 5-Türk dili 6-Français 7-Românesc 8-Polski 9-Português 10-Deutsch 11-한국어 12-Tiếng Việt 13-العربية 14-Bahasa Indonesia 15-فارسی 16-Україна	Language option.Display language selection. 0: English; 1: Simplified Chinese; 2: Traditional Chinese; 3: Spanish; 4: Russian; 5: Turkish; 6: French; 7: Romanian; 8: Polish; 9: Portuguese, 10: German, 11: Korean, 12: Vietnamese, 13: Arabic, 14: Bahasa Indonesia, 15: Persian, 16: Ukrainian (language).

1) Override Mode

No	Parameter	Range(defaults)	Notes
1	Override Mode	0: Disable 1: Enable	All shutdown alarm quantities are disabled except emergency shutdown and overspeed.

2) Delay time setting

No	Parameter	Range (default)	Notes
1	Start delay	0-6500.0s(5.0s)	The time during the engine starts after the remote signal is valid.
2	Return Delay	0-6500.0s(5.0s)	The time during deactivated to engine stop, after the remote signal is valid.
3	Preheat time	0-6500.0s (0.0s)	The time needed to be preheated before the starter on power.
4	Fuel output delay	0-6500.0s (2.0s)	The time the fuel valve relay outputs before the motor operates.
5	Cranking time	3.0-60.0s (8.0s)	Time of starter power up.
6	Crank rest time	3.0-60.0s (10.0s)	The waiting time before second power up when engine starts fail.(If diesel driven suction pump enabled, it is also can be crank rest time of diesel driven suction pump).
7	Safety delay	0-6500.0s (8.0s)	Low oil pressure, high water temperature, under speed, under frequency, under voltage, charge failure are all invalid during this time except for emergency stop and over speed.
8	Start idle time	0-6500.0s (5.0s)	Idle running time when crank successfully.
9	Warming-up time	0-6500.0s(10.0s)	The time needed for loading.
10	Cooling time	0-6500.0s(30.0s)	After unloading, the time of cooling down by radiator before stop. during the delay, if the remote start signal is valid, then engine will come into rated running.
11	Stop idle time	0-6500.0s (5.0s)	Idle-speed running time.
12	E.T.S. hold time	0-6500.0s (10.0s)	Stop solenoid on power time.
13	Fail to stop	0-6500.0s (30.0s)	If the RPM is 0 during the stop failure time, then the stop failure time is no needed.
14	Input alarm delay	1.0-60.0s (5.0s)	The alarm delay except for Aux.input.
15	Input warning delay	1.0-60.0s (2.0s)	The Aux.input warning delay.
16	Pulse speed up delay	0.1-60.0s(0.2s)	The interval time of the pulse speed up relay change.
17	Pulse speed down delay	0.1-60.0s(0.2s)	The interval time of the pulse speed down relay change.
18	Stop Delay on Manual	0-65000Min (65000Min)	For detailed functions, please refer to <Stop Delayed On Manual Mode> .

3) Engine setting

NO	Parameter	Range(<i>default</i>)	Notes	
1	CAN Protocol	0- Disabled 1: J1939 2: Cummins ISB 3: Cummins-CM850 4: Cummins QSX15-CM570 5: Cummins-CM850-PCC13X 6: Cummins-DCEC-QSZ13 7: Cummins-CCEC-QSN 8: Perkins 9: Perkins-1100 10: Volvo 11:188:GTSC1 VE	Built-in more than 180 ECU communication protocols, 11~188 CAN protocol (please refer to the detailed list) CAN protocol Option : the Engine parameters like RPM, oil pressure, water temperature are all from ECU data after choosing the relative protocol.	
2	Rated frequency	40.0-80.0Hz (50.0Hz)	When used in gensets: Some CAN protocols need to send a rated frequency setting command to be converted into speed: e.g. Cummins-CM850, Volvo-EMS2, etc.	
3	Rotation speed setting	Speed type	0: Speed sensor 1: W/L	If the setting is 0, (RPM sensor Disabled).
		Flywheel teeth	0-300 (118)	
		Rated RPM	500-4500RPM (1500)	Choose the meter range and calculate the alarm value. The number of the flywheel teeth is not 0 before checking the speed loss action.
		Action if RPM lost	Warning Alarm and stop	
		Loss of Speed Signal	0-3600.0s(5.0s)	
		Rated idle speed	500-4500rpm (750rpm)	ECU idle speed value.
4	Engine over speed setting	Alarm value	0-200%(114%)	Sets the engine rated speed percentage. Disables the engine over speed alarm when set to 200.  : In speed control mode, the over speed alarm value is the target speed * over speed alarm percentage.
		Return value	0-200%(110%)	
		Alarm action	0: Warning 1: Alarm and stop	
		Alarm delay	0-3600.0s(2.0s)	
5	Engine under speed setting	Alarm value	0-200%(80%)	Sets the engine rated speed percentage. Disables the engine under speed alarm when the set value is 0.  : In speed control mode, the under speed alarm value is the target speed * under speed alarm percentage.
		Return value	0-200%(85%)	
		Alarm action	0: Warning 1: Alarm and stop	
		Alarm delay	0-3600.0S(3.0S)	
6	Battery setting	Rated voltage	8.0-36.0V (24.0V)	When the battery voltage is lower than start value and remains 10s

		Charging start	8.0-30.0(25.6V)	under non-running status, then the relay is opened. When it is higher than the close value and remains 20Min, relay is closed. Once coming into running mode, there is no output. Sets the percentage of rated battery voltage. Disables the battery over voltage warning when set to 200. Disables the battery under voltage warning when the set value is 0. Detects D+ and B+ when their difference, and disables the charge failure warning when set to 30.
		Charging stop	10.0-36.0(27.8V)	
		Over battery	0-200%(135%)	
		Under battery	0-200%(67%)	
		Warning delay	0-3600.0S(60.0S)	
		Charger warning	1.0-30.0V(30.0V)	
		Charger warning delay	0-3600.0s(10.0s)	
7	Local start crank times	1-30 (1 time)	Crank times under local start mode.(If diesel driven suction pump enabled, it is also can be crank attempts of diesel driven suction pump).	
8	Auto start crank times	1-30 (3 times)	Crank times under auto mode.(If diesel driven suction pump enabled, it is also can be crank attempts of diesel driven suction pump).	
9	E.T.S. hold times	1-10(2 times)	The max E.T.S. hold on power shall be canceled once stop success under auto mode. the output interval time is " Fail to stop ".	
10	Crank disconnect	RPM Oil pressure RPM/Oil Pressure	1.If there is no oil pressure sensor, please don't choose the type. 2.Oil pressure switch input is not the crank condition 3.Please check if the running status, stop condition are according with crank condition. 4.Means either of the conditions can be acceptable as crank condition. But all of them should be meet together to regard as stop condition.	
11	Crank disconnect conditions	RPM disconnect Oil pressure disconnect Oil pressure delay	0-200%(24%) 0-400kpa(200kpa) 0-60.0s (0.0s)	According to the judgement of starting success conditions, the judgement conditions are met, the starting is considered successful, and the crank disconnect.
12	Pre-oil supply setting	Pre-oil supply rest Time	0-12h (0.0h)	When output is configured as "Pre-oil supply", it is the interval between the completion of the pre-fuel supply output and the next Pre-oil supply output in standby status. If time is 0,Pre-oil supply is not output in standby status.
		Pre-oil supply output time	3—30.0s(5.0s)	It is Pre-oil supply output time when output configured as "Pre-oil supply".

13	Low battery start protection	0-Disable 1-Enabled	When this function is enabled, it will judge whether the battery voltage is lower than the warning value before the starter motor outputs, if it is lower than the warning value, the starter motor will not output, and the screen will indicate “ Low Battery voltage, please start manually! ”
----	------------------------------	-------------------------------	--

4) Suction Pump setting

No	Parameter	Range(defaults)	Notes
1	Suction pump crank	0: Disable 1: D-driven suction pump 2: E-driven suction pump	Select whether to start the suction pump and pump type.
2	D-driven suction pump fault shutdown delay	0-3600.0S(90.0S)	Time for waiting press to suction pump (“Waiting Press. to” input is active).
3	D-driven suction pump crank output time	0-3600.0S(5.0S)	Time for D-driven suction pump crank output.
4	D-driven suction pump stop output time	0-3600.0S(15.0S)	Time for D-driven suction pump stop output.
5	Outlet press when E-driven suction pump stopped	0-1000kpa(100kpa)	It is pressure when “E-driven Pump Start” input stops outputting.

5) Sensor setting

No	Parameters	Range(defaults)	Notes	
1	AUX.SENSOR 1	Users Configured name	Related Settings Please refer to User Configurable Sensor Generality Settings	
		Sensor Type		0: Disable
		Signal Type		1: Resistive type
		Display Unit		1: ℃
		Curve Type		0
		Lower range limit		0
		Upper range limit		0
		Sensor Disconnect Action		0: Disable
		Alarm Action		0:Warning
		High Alarm value		6000
		Low Alarm Value		0
		Alarm Action Delay		5.0S
	Users configured curve setting			
2	AUX.SENSOR 2	Users Configured name	Related Settings Please refer to User Configurable Sensor Generality Settings	
		Sensor Type		0: Disable
		Signal Type		1: Resistive type
		Display Unit		1: ℃
		Curve Type		0
		Lower range limit		0
		Upper range limit		0

		Sensor Disconnect Action	0: Disable	
		Alarm Action	0:Warning	
		High Alarm Value	6000	
		Low Alarm Value	0	
		Alarm Action Delay	5.0S	
		Users configured curve setting		
3	AUX.SENSOR 3		0: Disable	Related Settings Please refer to User Configurable Sensor Generality Settings
4	AUX.SENSOR 4		0: Disable	
5	AUX.SENSOR 5		0: Disable	
6	AUX.SENSOR 6		0: Disable	
7	Heating Settings	Open Value	-50℃-300℃ (-50 ℃)	Heating Control Setting Minimum Disable
		Close Value	-50℃-300℃ (-50 ℃)	
		Maximum time	0-7200Min(0Min)	
		Associated connection Sensors	AUX.SENSOR1~6	Associated Temperature Sensor Valid
8	Cooling Settings	Open Value	-50℃-300℃ (-50 ℃)	Cooling Control Setting Minimum Disable
		Close Value	-50℃-300℃ (-50 ℃)	
		Maximum time	0-7200Min(0Min)	
		Associated connection Sensors	AUX.SENSOR1~6	Associated Temperature Sensor Valid
9	Fuel pump setting	Open Value	0-100% (25%)	The fuel pump switches on when the fuel level is below the set value and lasts for 10s.
		Close Value	0-100% (80%)	
		Maximum fuel pump on time	0-65000s (0s)	The fuel pump switches off when it is higher than the set value and lasts 1s. Time minimum 0 disables the fuel pump output function.
		Filling detection	0-600s(30S)	When the fuel pump is operating, if an increase in the sensor fuel level value of less than 3% is detected during this time, a fuel filler system fault warning is reported.
		Tank volume	0-10000L(0L)	
		Associated connection Sensors	AUX.SENSOR1~6	Associated Fuel Sensor Valid
10	Outlet Pressure setting	Pump head	0: Disable 1: Enable	
		Pump flow	0: Disable 1: Enable	
		Static pressure	-10000-10000kpa (0kpa)	Setting static pressure of water pump outlet port.
		Rated flow	0-10000m³/h (1000m³/h)	Rated working flow of engine.

		Flow unit	0: m ³ /h 1: L/s 2: L/Min	
		Over flow Warn	0-200%(110%)	Warning if flow value is higher than this value during engine running. Enable alarms, delay value and return value can be set.
		Over flow shutdown	0-200%(120%)	Shutdown if flow value is higher than this value during engine running. Enable alarms and delay value can be set.
		Flow Curve Set		Set the relationship between the different outlet pressures and its corresponding flows.
		Associated connection Sensors	AUX.SENSOR1~6	Associated Outlet Pressure Sensor Valid
11	Choke setting	Choke closing temperature	20—200℃ (40 ℃)	Used to control the choke, which operates when the engine temperature falls below this setting.
		Choke closing delay	0—200.0s(3.0s)	Choke closing delay time.
		Associated connection Sensors	AUX.SENSOR1~6	Associated Temperature Sensor Valid
User Configurable Sensor Generality Settings				
Users Configured name	0: Disable ; 1:Users Configured sensor name; 2:Potentiometer; 3: Temperature sensor; 4: Oil Pressure Sensor; 5: Liquid level sensor 6: Fuel level sensor; 7: Pipe Network pressure sensors 8: Inlet pressure sensor; 9: Outlet pressure sensor 10: Torque converter oil temperature sensor; 11: Water level sensor; 12: water pressure sensor; 13: Coolant temperature sensor; 14: Exhaust gas temperature sensor; 15: Exhaust gas pressure sensor; 16: Intake pressure sensor; 17: Primary pressure sensor; 18: Secondary pressure sensor; 19: System pressure sensor; 20: Flow sensor.			
Sensor Type	0: Disable 1: Temperature type sensor 2: Pressure type sensor 3: Percentage sensor 4: Flow rate type			
Signal Type	1: Resistive type 2: Voltage type 3: Current type			
Display Unit	Resistive type	1:℃	2:°F	
	Voltage type	1:Bar	2:kPa	3:PSI 4:MPa
	Current type	1:%		
	Flow rate type	1: m ³ /h	2: L/s	3:L/Min

Curve Type	Resistive type	Pressure type	1:Users Configured Resistive Pressure Sensor 2:VDO 0-10Bar 3:MEBAY-003B 4:SGH 5:SGD 6:SGX 7:CURTIS 8:DATCON 10Bar 9:VOLVO-EC 10:3015237 11:WEICHA1 0-0.6Mpa 12:GENCON 0-10Bar
		Temperature type	1:Users Configured Resistive Temperature Sensor 2:VDO 40-120°C 3:MEBAY-001B 4:MEBAY-Mier 5:SGH 6:SGD 7:SGX 8:CURTIS 9:DATCON 10:VOLVO-EC 12:3015238 12:PT100 13:WEICHA1 40-120°C 14:GENCON 40-120°C
		Percentage	1:Users Configured Resistive Percentage Sensor 2:0-100Ω 3:100-0Ω 4:0-107Ω 5:107-0Ω 6:0-180Ω 7:180-0Ω 8:10-180Ω 9:180-10Ω 10:10-120Ω 11:120-10Ω 12:0-90Ω 13:90-0Ω 14:0-30Ω 15:30-0Ω 16: 73-10Ω 17:240-33Ω 18:33-100Ω 19:0-200Ω 20:200-0Ω 21: 0-190Ω

			22: 190Ω-0Ω
	Voltage type	1: Users Configured voltage type 2: 0-5V 3: 0.5-4.5V	
	Current type	1: Users Configured current type 2: 4-20mA	
Lower/Upper Range limit setting	Pressure type sensor	0-1000MPa	
	Temperature type sensor	lower limit	-100 - 1000℃
		upper limit	-100 - 1000℃
	Percentage sensor	lower limit	0-100%
		upper limit	5-100%
Flow rate type	0 - 6000m³/h		
Sensor Disconnect Action	1:Disable 2:Warning 3:Alarm and stop		
Alarm Action	1: Warning 2:Alarm and stop 3:Stop after heat dissipation		
High Alarm Value	0 - 6000		
Low Alarm Value	0 - 6000		
Alarm Action Delay	0 - 6000s		
Users configured curve setting	 Sensor curve can be Users Configured by panel buttons, resistance and according value should be input,MAX 15 groups ,MIN 2 groups. Rule: resistance should be input from small to large.		

6) Input setting

No	Parameters	Range(defaults)	Notes	
1	AUX. INPUT 1 (Pin19)	13.Emergency shutdown		
2	AUX. INPUT 2 (Pin20)	29:Remote start		
3	AUX. INPUT 3 (Pin21)	4:High water temperature alarm switch		
4	AUX. INPUT 4 (Pin22)	2:Low oil pressure alarm switch		
5	AUX. INPUT 5 (Pin23)	0:Disable		
6	AUX. INPUT 6 (Pin24)	0:Disable		
7	AUX. INPUT setting	Function	0-50	Fixed projects: Only fixed functions and valid methods can be selected
		Valid Type	Normal close Normal open	
		Action	Warning Alarm	Users Configured projects: All options can be set when valid when (Function 1: Users Configured).is selected.
		Point	Disable Standby From crank From safety on After rated running Always	
		Delay	0-3600S	
AUX. input function table				
0.Disable.				
1.Users Configured.				

2. **Low oil pressure alarm.**
3. **Low oil pressure warning.**
4. **High water temperature alarm.**
5. **High water temperature warning.**
6. **Low water level alarm.**
7. **Low water level warning.**
8. **Low fuel level alarm.**
9. **Low fuel level warning.**
10. **Lamp Test:** When the input is valid: the indicator lights are all on.
11. **Louver status input.**
12. **Meter mode:** all output are disabled, alarm and warns are invalid.
13. **Emergency stop.**
14. **Reset Alarm:** Can reset shutdown alarm when input is active.
15. **Silent alarm:** audio alarm output is disabled if there is signal output.
16. **External instant warning.**
17. **External instant alarm.**
18. **Reserved.**
19. **Reserved.**
20. **Reserved.**
21. **Panel lock:** any button except for page button is disabled if there is signal output.
22. **Auto stop inhibit:** In auto mode, during engine normal running, when input is active, inhibit engine shutdown automatically.
23. **Auto start inhibit:** In auto mode, inhibit engine start automatically when input is active.
24. **Scheduled run inhibit:** In auto mode, inhibit scheduled run engine when input is active.
25. **Crank success input:** When this function is active, it means the engine is started successfully. If this function is configured, the speed and oil pressure crank success conditions will be invalid.
26. **Idle/High speed:** Enter into idle mode when input is active; return back to high-speed running when input is inactive.
27. **Idle/High Speed (Manual):** In auto mode, it doesn't return back to idle mode when input is active; In manual mode, it enters idle mode when input is active; return back to high-speed running when input is inactive.
28. **Idle/High speed (Memory):** In the normal running, it enters idle mode when input is active; return back to last adjusted high-speed value when input is inactive. It is only active for the current start and still run to rated speed for next start.
29. **Remote start:** In auto mode, when input is active, engine can be started automatically.
30. **Remote stop:** In auto mode, when input is active and remote start input is inactive, engine can be stopped automatically.
31. **Manual Start Input:** In auto mode, when input is active, engine can be started automatically; when input is inactive, engine can be stopped automatically.
32. **Simulate Stop key:** An external button (unlatched) can be connected and pressed as simulate panel.
33. **Simulate Manual key:** An external button (unlatched) can be connected and pressed as simulate panel.
34. **Simulate Auto key:** An external button (unlatched) can be connected and pressed as simulate panel.
35. **Simulate Start key:** An external button (unlatched) can be connected and pressed as simulate panel.
36. **Simulate Speed Regulation key:** An external button (unlatched) can be connected and pressed as simulate panel.
37. **Reset maintenance time:** Controller will set maintenance time and date as default

when input is active.

- 38.External charging failure:** When input is active, charging failure warning alarm occurs.
- 39.Speed up:** When the input is valid: the speed increases according to the set acceleration step;(Always effect, always according to the set acceleration step)
- 40.Speed down:** When the input is valid: the speed decelerate according to the set deceleration step;(Always effect, always according to the set deceleration step)
- 41.D-driven suction pump started:** When input port is active, it indicates diesel driven suction pump started successfully.
- 42.Press. to suction pump:** When input port is active, it indicates pressure has been to suction pump.
- 43.Water gun On/Off input:** (1,Normal status: if input is active, bypass control is output between start idle to stop idle period.)(2, Idle running status: if input is active, engine operates idle running to normal running, meanwhile, bypass control starts output (if configured).
- 44.High water level input:** In auto mode, when input is active, engine can be started automatically (drain flood).
- 45.Low water level input:** In auto mode, when input is active and high water level input is inactive, engine can be stopped automatically (drain flood)
- 46.DPF Regeneration Inhibit:**This input is used to override the ECU function and prevent the regeneration of the diesel particulate filter.
- 47.DPF Regeneration:** This input is used to override the ECU function and activate the regeneration of the diesel particulate filter.
- 48.Raise Speed Input :** After the input is valid, the speed will increase once (set acceleration step), which can be connected to the self-reset button.
- 49.Drop Speed Input :** After the input is valid, the speed is reduced once (set deceleration step), and the self-reset button can be connected.
- 50.Auto start/stop Input :** In auto mode, the engine can be started automatically when the input is valid and stopped automatically when the input is invalid.
- 51. Reserved.**

7) Output setting

No	Parameters		Range(defaults)	Notes
1	AUX.OUTPUT 1 (Pin5)	Function	0-80(24:Fuel output)	Set the default value (please refer to the AUX. Output function table) Set the state when the AUX. output is valid.
		Valid Type	0-Normal open 1-Normal close	
2	AUX.OUTPUT 2 (Pin7)	Function	0-80(13:Public warning output)	
		Valid Type	0-Normal open 1-Normal close	
3	AUX.OUTPUT 3 (Pin8)	Function	0-80(14:Public alarm output)	
		Valid Type	0-Normal open 1-Normal close	
4	AUX.OUTPUT 4 (Pin9)	Function	0-80(34:E.S.T. hold)	
		Valid Type	0-Normal open 1-Normal close	
5	AUX.OUTPUT 5 (Pin10,11)	Function	0-80(0:Disable)	
		Valid Type	0-Normal open 1-Normal close	
6	AUX.OUTPUT 6 (Pin12,13,14)	Function	0-80(0:Disable)	
		Valid Type	0-Normal open	

1-Normal close

AUX. Output function table
0.Disable

- 1.**Input 1 valid:** Action when input 1 is valid.
- 2.**Input 2 valid:** Action when input 2 is valid.
- 3.**Input 3 valid:** Action when input 3 is valid.
- 4.**Input 4 valid:** Action when input 4 is valid.
- 5.**Input 5 valid:** Action when input 5 is valid.
- 6.**Input 6 valid:** Action when input 6 is valid.
- 7.**Associated connection AUX.SENSOR 1 :** The association can users configured outputs of sensor 1 (Disconnect, warning, alarm, etc.).
- 8.**Associated connection AUX.SENSOR 2 :** The association can users configured outputs of sensor 2 (Disconnect, warning, alarm, etc.).
- 9.**Associated connection AUX.SENSOR 3 :** The association can users configured outputs of sensor 3 (Disconnect, warning, alarm, etc.).
- 10.**Associated connection AUX.SENSOR 4 :** The association can users configured outputs of sensor 4 (Disconnect, warning, alarm, etc.).
- 11.**Associated connection AUX.SENSOR 5 :** The association can users configured outputs of sensor 5 (Disconnect, warning, alarm, etc.).
- 12.**Associated connection AUX.SENSOR 6 :** The association can users configured outputs of sensor 6 (Disconnect, warning, alarm, etc.).
- 13.**Public warning output:** when there is any warning output.
- 14.**Public alarm output:** Action when engine common warning, common shutdown, common trips alarm.
- 15.**Audio alarm:** when there is any alarm output, the Audio controls.
- 16.**Lamp Test Output:** Output when lamp test is in progress.
- 17.**Preheat mode 1:** preheat before start.
- 18.**Preheat mode 2:** preheat before crank success.
- 19.**Preheat mode 3:** preheat after safety delay.
- 20.**Louver control:** Outputs when the engine is switched on, and stops when the engine is stopped.
- 21.**Choke control:** choke will be started after crank success and off after delay.
- 22.**Fuel Pre-supply Output:** 1)In standby status, "Fuel Pre-supply" output is active, it will cycle output based on the pre-set "Fuel Pre-supply Rest Time" and "Fuel Pre-supply Time"; if "Fuel Pre-supply Rest Time" is set as 0h, it will not output. 2)"Fuel Pre-supply Time" is outputting before starting. If the pre-heat time is not configured, the fuel pre-supply phase outputs; if pre-heat time is configured, the preheat phase outputs.
- 23.**Oil Pre-lubrication output:** Action in period of pre-heating, cranking and crank rest time.
- 24.**Fuel output:** output once engine starts and off till stable.
- 25.**Crank output:** output once cranking, no output in other mode.
- 26.**Crank Success Output:** Close when detects crank success signal.
- 27.**Engine block running:** output under running, off once RPM is lower than cranking RPM. The crank success condition can be set.
- 28.**Idle speed control:** used for speed controller, there is output under idle but no output under high speed.
- 29.**Speed-up control:** there is output when coming into high speed warming up, which time is **Longest RPM-up time**.
- 30.**High speed control:** The output is valid after idle delay is completed, and the output is closed after high-speed heat dissipation.
- 31.**Speed-down control:** the output time is shutdown idle delay during shutdown idle or

shutdown on power procession.

32. **Pulse speed up output:** the pulse shall be sent out in the interval of “Pulse speed up delay” under speed –up.
33. **Pulse speed down output:** the pulse shall be sent out in the interval of “Pulse speed down delay” under stop idle speed.
34. **E.S.T. hold:** shutdown output, it is used for engine with stop solenoid. when the setting value of shutdown delay is over, then it is off.
35. **Reserved.**
36. **Rated running:** there is output under rated running.
37. **Heating output:** output according to the heating condition setting;
38. **Cooling output:** output according to the cooling condition setting;
39. **Fuel pump output:** output according to fuel pump setting conditions;
40. **Oil pump control:** when the CAN protocol is Yuchai LMB. When the engine is in the standby state, the oil pump controls the output every 30 minutes. If the oil pressure is higher than 100kPa or the output is 1 minute (whichever comes first), the oil pump control output will stop; when the engine is in the preheating state, the oil pump control will always output.
41. **Battery charging control:** there is output if the voltage is lower than the preset value under standby status and shutdown after start and in running status.
42. **System in stop:** there is output under stop mode.
43. **System in manual:** there is output under manual mode.
44. **System in auto:** there is output under auto mode.
45. **Override output:** The controller output when it is in Override mode.
46. **ECU power:** apply to electrical ECU engine, used for control ECU power.
47. **ECU stop:** apply to electrical ECU engine, used for control ECU shutdown.
48. **ECU warning:** there is a warn signal from ECU.
49. **ECU alarm:** there is an alarm signal from ECU.
50. **ECU communication failure alarm:** Cannot communicate with ECU.
51. **Reserved.**
52. **ECU communication failure warning:** Output when ECU Communication Failure Warning.
53. **Fail to start alarm:** Output when the engine fail to start.
54. **Fail to Stop alarm:** Output when the engine fail to stop alarm.
55. **Under battery voltage warning output :** Output when the battery voltage is low warning.
56. **Over battery voltage warning:** Output when the battery voltage is low warning.
57. **Charging failure warning:** Output when the engine charger fails to charge.
58. **Floating charger fault warning:** Output when the floating charger fails to charge.
59. **Emergency stop alarm:** Output when emergency stop alarm.
60. **Over speed warning:** Output when Over Speed Warning.
61. **Over speed alarm:** Output when Over Speed alarms.
62. **Under speed warning:** Output when engine under speed warning.
63. **Under speed alarm:** Output when engine under speed alarm.
64. **D-driven Pump Start:** Output when suction pump set as diesel-driven suction pump.
65. **D-driven Pump Stop:** Output when suction pump set as diesel-driven suction pump.
66. **E-driven Pump Start:** Output when suction pump set as electronic-driven suction pump. It stops output when engine stopped.
67. **Bypass Control Output:** The input port is configured as “Water Gun On/Off Status Input” and is output between the “Start Idle” and “Stop Idle” when input is active.
68. **Over Flow Shutdown:** Action when engine over flow shutdown alarm occurs.
69. **Over Flow Warning:** Action when engine over flow warning alarm occurs.

- 70.DPF Regeneration Inhibit Request:** when the output is active , the diesel particulate filter regeneration inhibit.
- 71.DPF Regeneration Requested:** Outputs an indication when diesel particulate filter regeneration is requested;
- 72.DPF Forced Regeneration:** When the output is valid: forced regeneration of the diesel particulate filter.
- 73.DPF Regeneration In Progress:** Output indication when diesel particulate filter regeneration is in progress.
- 74.-80 Reserved.**

8) CAN communication

No	Parameter	Range(<i>default</i>)	Notes
1	ECU failure	Disable Warning Alarm and Stop	ECU communication failure.
2	ECU warning	Disable/ Enable	ECU warnings enable.
3	ECU alarm	Disable/ Enable	ECU alarms enable.
4	Mask SPN	0-12	Up to 12 sets of alarm codes can be input, and the controller will not respond to the input alarm codes.
5	Reserved		
6	CAN communication rate	0-Automatic detection 1-125Kbps 2-250Kbps 3-500Kbps	CAN communication rate
7	Low oil pressure Alarm from ECU	0-999kpa (103kpa)	When the oil pressure data comes to the ECU, set the low oil pressure alarm value.
8	Coolant temperature high alarm from ECU	20-200℃ (98 ℃)	When the Coolant temperature data comes to the ECU, set the coolant temperature high alarm value.
9	ECU Pressure/Temp unit	℃/kPa ℃/Bar ℃/PSI ℉/kPa ℉/Bar ℉/PSI	The unit is displayed when the sensor data source is with the ECU.
10	ECU speed control address	00000000 — FFFFFFFF (0C000003)	When communication protocol selection 31:J1939-C is in valid, the controller can configured the TSC1 message ID address to be sent to the ECU.
11	ECU speed control data	00 00 00 00 00 00 00 00— FF FF FF FF FF FF FF FF (01 xx xx 00 00 00 00 00)	When communication protocol selection 31:J1939-C is in valid, the controller can configured the format of the TSC1 speed control data message sent to the ECU.
12	ECU speed sending	5-6000ms (10ms)	When communication protocol

	interval		selection 31:J1939-C is in valid, the controller can configured the interval time TSC1 speed control data messages sent to the ECU.
--	----------	--	---

9) Adjust Speed Setting

No	Parameter	Range(<i>default</i>)	Notes
1	Speed control type	0:Disable 1:CAN speed control-keypad 2:CAN speed-switching 3:CAN speed - 1 or 2 4:CAN speed - potentiometer	Selecting the speed control method.
2	Maximum speed	500-4500RPM (2500RPM)	Sets the maximum speed for the engine speed control.
3	Speed up step	1-1000RPM (50RPM)	Sets the step of speed increase when the  key is pressed once or the acceleration switching amount is actuated once.
4	Speed down step	1-1000RPM (50RPM)	Set the step size of the speed reduction when the  key is pressed once or the deceleration switching volume is actuated once.
5	Potentiometer resistance	100-5000Ω (4700Ω)	Set the resistance value of the external speed potentiometer; the potentiometer adjusts the engine speed from "electronically controlled idle value" to "maximum speed value".

A) Module settings

No	Parameter	Range(defaults)	Notes
1	Primary Modes	STOP Manual Auto Auto save	The primary modes on power, easy for user operation.
2	Host and slave mode	0: Host mode 1: Slave mode	Select the instrument communication mode, the slave can read and display the parameters of the host through the RS485 port.
3	User password	00000-65535 (07623)	Change the password.
4	Controller ID	1-255(16)	The IP built by controller and PC.
5	RS485 baud rate	0-4800 1-9600 2-19200 3-38400 4-57600 5-115200	RS485 communication baud rate.
6	Start screen display time	0-20.0s (5.0s)	Start screen display time,0: No-display.
7	LCD contrast	50-127(106)	Set the LCD display contrast.
8	Saving mode	5.0-6000.0s (600.0s)	LCD light will be closed automatically without any button pressed after delay. If setting as 6000.0s, back light always lighted.

9	Homing display	5.0-600.0s (600.0s)	The time when the page reverts back to the home page. If setting as 600.0s: disabled.
10	LOGO delay display under standby	5.0-6000.0 (6000.0s)	Start screen will be opened without any button pressed after delay. If setting as 6000.0s: disabled.
11	ECU page	Disable/ Enable	Set whether the ECU page is displayed.
12	Date/Time	2000/01/01-2099/12/31	Internal calendar, please calibrate regularly.
13	Current time	00:00-23:59	

B) Automatic maintenance

No	Parameter	Range(defaults)	Notes
1	Working plan format	Disable Every month Every week	This mode must be under auto mode. Working plan is disabled once setting as disable. The working plan will be executed according the chosen date when setting as every month. The working plan will be executed according the chosen date when setting as every week.
2	Maintenance date per month	From 1 st to 31 st Default: the first day	The date chosen for every month.
3	Maintenance date per week	Monday to Sunday Default: Sunday	The date chosen for every week.
4	Reserved		
5	Maintenance start time	00:00-23:59 (00:00)	Maintenance start time setting.
6	Maintenance running time	1-120m (5min)	Maintenance running time setting.

C) Maintenance Plan

NO	Parameter	Range(default)	Notes
1	Countdown to oil change	0-5000h (5000h)	When it is set as 5000, then this function is disabled.
2	Air filter H	0-5000h (5000h)	
3	Fuel filter H	0-5000h (5000h)	
4	Oil filter replacement date	2000/01/01 -2099/12/31	When it is set as 2000/01/01, this function is disabled.
5	Air filter D	2000/01/01 -2099/12/31	
6	Fuel filter D	2000/01/01 -2099/12/31	
7	engine oil filter expires action	Warn Delayed alarm stop Alarm and stop	engine action after the oil expires.
8	Air filter expiration action	Warn Delayed alarm stop Alarm and stop	engine action after the air filter expires.
9	Fuel filter expiration action	Warn Delayed alarm stop Alarm and stop	engine action after the fuel filter expires.

10	Maintenance due delay time	0-500.0h(1.0h)	If after the maintenance expires, after the engine starts successfully, after the set time, the maintenance expired shutdown alarm will be reported.
11	Maintenance expiry reset password	0-65535 (06869)	When the maintenance countdown time arrives, enter the password to reset the maintenance countdown time, this password cannot be the same as the parameter setting password.

D) Limited time function

NO	Parameter	Range(<i>default</i>)	Notes
1	Factory limited time	0-5000h(5000h)	Set the accumulated time allowed by the manufacturer to run the engine. After the timer expires, the engine will not run. Entering a temporary password can ensure that the engine will start at one time. When set to 5000, this function is disabled.
2	Temporary password one	0-65535(11111)	After the manufacturer's time limit is set, the temporary password 1 will become invalid after one use;
3	Temporary password two	0-65535(22222)	After the manufacturer's time limit is set, the temporary password 2 will become invalid after one use;
4	Temporary password three	0-65535(33333)	After the manufacturer's time limit is set, the temporary password 3 will become invalid after one use;
5	Factory release password within a limited time	0-65535(44444)	After the manufacturer's time limit is set, enter this password to permanently unlock the password;

E) Duty Plan setting

No	Parameter	Range(<i>default</i>)	Notes
1	Working plan	Disable Enable 1: remote start Enable 2: running always	Working plan start condition.
2	Start time	00:00-23:59 (08:00)	The start time allowed.
3	End time	00:00-23:59 (17:00)	The end time allowed (the next day is valid).
4	Dates	1-31	Multiple choices according to the reality. The longest running time is 24 hours.

◆ CAN Protocol Detailed Table

0.Disable	95.Isuzu Tier 4 Final
1.J1939	96.Isuzu Tier 4 Final DOC Only
2.Cummins ISB	97.Iveco EDC7C1
3.Cummins-CM850	98.Iveco EDC7UC31
4.Cummins QSX15-CM570	99.Iveco EDC62

5.Cummins-CM850-PCC13X	100.Iveco T3
6.Cummins-DCEC-QSZ13	101.JCB DCM3.3
7.Cummins-CCEC-QSN	102.JCB DCM7.24
8.Perkins	103.JCB DCM7.24 No SCR
9.Perkins-1100	104.John Deere
10.Volvo	105.John Deere iT4
11.Volvo-EMS2	106.John Deere T4f
12.Volvo-EMS2b	107.John Deere T4f CVT
13.Volvo-EDC4	108.John Deere T4f NoDPF
14.Scania	109.Kipor ECM
15.Scania-kw2000	110.Kipor V ECM
16.Scania-kw2k-coo	111.KOEL
17.John Deere	112.KOEL 6K
18.mtu-ADEC	113.KOEL HA2
19.mtu-ADEC-SAM	114.KOEL K4300
20.mtu-ADEC-303	115.KOEL N
21.mtu-ADEC-304	116.Kohler HD
22.BOSCH	117.Kohler KDI Stage V
23.GTSC1	118.Kohler KDI Stage V SCR
24.MTSC1	119.Kohler T4f
25.YUCHAI-YCECU	120.Kohler T4f + DPFREGST
26.Y&C ENGINE-YC6K	121.Kohler T4f no DCU
27.WEICHAI-WISE15	122.Kohler T4f no SCR
28.CHANGCHAI-ECU15	123.Kubota ECU
29.YUCHAI-LMB	124.Kubota LSI
30.MAN	125.Kubota Stage V
31.J1939-C	126.Kubota T4f DOC Only
32.SDEC-H/D	127.Lombardini KDI
33.SDEC-E	128.Mahindra BS4
34.YTO	129.Mahindra N1
35.DEUTZ EMR2-2001	130.Mahindra NG
36.DEUTZ EMR2-2012	131.Mahindra NG A46
37.DEUTZ EMR3	132.MAN EDC17
38.DEUTZ EMR4	133.MAN MFR
39.NEVED-ECU13	134.MAXXFORCE
40.Cummins-CM2150	135.MTU ADEC
41.WP6-2	136.MTU ECU8

42.AgCo EEM4S5	137.MTU ECU8 SAM
43.Baudouin WISE10B	138.MTU ECU9
44.Baudouin Wise15	139.MWM16
45.CAT A4E2	140.Perkins 1300
46.CAT A4E2v2	141.Perkins 1600
47.CAT A4E2v3.1	142.Perkins A4E2
48.CAT ADEM4	143.Perkins A4E4 A5E2 Dual ECU T4F
49.CAT C3.4B T4f	144.Perkins A5E2
50.Cummins CM558	145.Perkins A5E2v2
51.Cummins CM570	146.Perkins A6E2
52.Cummins CM570 Ind	147.Perkins A6E2 EU3
53.Cummins CM850	148.Perkins A6E10
54.Cummins CM2150E	149.Perkins A6E11
55.Cummins CM2250	150.Perkins ADEM3
56.Cummins CM2350	151.Perkins ADEM4
57.Cummins CM2350 G-Drive Stage	152.Perkins EDC17C49
58.Cummins CM2350 G-Drive T4f	153.Perkins Generic T4F Dual ECU
59.Cummins CM2350 Ind, Stage V	154.Powerlink Gas
60.Cummins CM2350 Ind	155.PowerLink Gas V1
61.Cummins CM2850	156.PowerLink Gas V2
62.Cummins CM2880 G-Drive	157.PSI 4G
63.Cummins CM2880 Ind	158.PSI IAT
64.Cummins QSZ	159.Scania E3
65.Daimler CPC4	160.Scania OCE
66.Detroit DDEC	161.Scania S6
67.Deutz EMR2	162.Scania S8
68.Deutz EMR3	163.Scania S8 Single
69.Deutz EMR4	164.Scania S8 Single-speed Stage V
70.Deutz EMR4 CVT	165.Scania S8 SS Stage V HEST
71.Deutz EMR5	166.Siemens NG
72.Doosan G2 Stage V	167.Sisu EEM3
73.Econtrols GCP	168.Volvo EDC3
74.FPT EDC7UC31 i T4	169.Volvo EDC4
75.FPT EDC17C49 T4B	170.Volvo EMS2
76.FPT EDC17CV41	171.Volvo EMS2 VE
77.FPT MD1CE101	172.Volvo EMS2.3
78.FPT MD1CE101 Tier3	173.Volvo EMS2.3 VE

79.FPT MD1CS069	174.Volvo EMS2.4
80.FPT MD1CS069 No SCR	175.Volvo EMS2b
81.Generac STM Dual (SPTF-MotorT)	176.Weichai Wise 15
82.Generac STP Dua	177.Weifu ECU
83.Generic J1939	178.Woodward SECM70
84.Generic Plus	179.Yanmar ECO
85.GM PSI	180.Yanmar 4TN88G
86.Hatz EDC17	181.Yanmar T4F TNV
87.Hatz EDC17 3K 1200 Idle	182.Yanmar TNV Stage V
88.Hatz EDC17 SV	183.Yuchai ECU
89.Isuzu 4H	184.Yuchai ECU 1000rpm
90.IsuZu 4J	185.Zenith ECU
91.Isuzu 4J T4f	186.LiFan001
92.Isuzu 4L	187.GTSC1 TE
93.Isuzu 6H	188.GTSC1 VE
94.Isuzu 6W	

Fault finding

Symptoms	Possible Solutions
Controller no response with power	Check DC voltage. Check DC fuse. Check if the terminal 1 and 2 is with battery voltage.
Units shutdown	Check the water/cylinder temperature is too high or not. Check DC fuse.
Emergency Stop	Check the emergency stop button. Check that the voltage of the controller's 3 feet to the ground should be the battery voltage. Check the controller connection.
Low oil pressure alarm	Check oil pressure sensor and its wiring. Check the oil pressure sensor type and controller settings must be consistent. Check whether the low oil pressure sensor is normal.
High temperature alarm	Check temperature sensor and its wiring. Check the temperature sensor type and controller settings must be consistent. Check whether the temperature sensor is normal.
Shutdown Alarm in running	Check related switch and its connections according to the information on LCD. Check programmable inputs.
Fail to start	Check the engine fuel circuit and its connecting wires; Check whether the starting battery voltage is normal; Check the speed sensor and its connecting wire;
Starter motor does not respond	Check the wiring to the starter. Check start battery.

USB communication is abnormal	Check the USB connection. Check whether the USB port of the computer is normal. Check whether the USB driver is installed.
RS485 cannot communicate normally	Check the connection. Check if the communication ID number setting is correct. Check if the A and B lines of RS485 are reversed. Check if the RS485 communication line driver is installed or not. Check if the communication port of the PC is damaged. Add a 120 Ω resistor between the AB of the controller RS485.
ECU warning or stop	Get information from LCD of alarm page; If there is detailed alarm, check engine according to description. If not, please refer to engine manual according to SPN alarm code.